WORK INSTRUCTION

Document ID: DOC-0002546
Project: PRJ-017
Uploaded on: 2026-02-24
Uploaded by: user149
Export class: EAR99

Assembly of P-100909 at plant PLT04

Part Number: P-100909
Revision: A.1
Plant: PLT04
Station: ST-76
Torque (Nm): 5
Cycle time (s): 74

Step 1: Clean mating surface

Step 2: Torque to specification

Step 3: Fit fasteners

Step 4: Apply thread locker

Step 5: Move to next station

Step 6: Move to next station

Assembly of P-102873 at plant PLT03

Part Number: P-102873
Revision: A.1
Plant: PLT03
Station: ST-57
Torque (Nm): 5
Cycle time (s): 104

Step 1: Apply thread locker

Step 2: Record result

Step 3: Move to next station

Step 4: Fit fasteners

Step 5: Record result

Step 6: Fit fasteners

Step 7: Apply thread locker

Step 8: Torque to specification