WORK INSTRUCTION

Document ID: DOC-0002550
Project: PRJ-002
Uploaded on: 2026-02-26
Uploaded by: user177
Export class: EAR99

Assembly of P-100741 at plant PLT01

Part Number: P-100741
Revision: A.1
Plant: PLT01
Station: ST-40
Torque (Nm): 8
Cycle time (s): 103

Step 1: Torque to specification

Step 2: Inspect incoming part

Step 3: Fit fasteners

Step 4: Move to next station

Step 5: Record result

Step 6: Apply thread locker

Step 7: Torque to specification

Step 8: Record result

Assembly of P-103715 at plant PLT01

Part Number: P-103715
Revision: A.1
Plant: PLT01
Station: ST-17
Torque (Nm): 20
Cycle time (s): 248

Step 1: Torque to specification

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Visual check

Step 5: Fit fasteners

Step 6: Record result

Step 7: Visual check

Step 8: Torque to specification

Assembly of P-102976 at plant PLT01

Part Number: P-102976
Revision: A.1
Plant: PLT01

Station:	ST-92
Torque (Nm):	12
Cycle time (s):	80

Step 1: Apply thread locker

Step 2: Torque to specification

Step 3: Apply thread locker

Step 4: Torque to specification

Step 5: Fit fasteners

Step 6: Clean mating surface

Step 7: Apply thread locker