WORK INSTRUCTION

Document ID: DOC-0000337
Project: PRJ-004
Uploaded on: 2023-04-13
Uploaded by: user033
Export class: EAR99

Assembly of P-100377 at plant PLT03

Part Number: P-100377
Revision: A.1
Plant: PLT03
Station: ST-30
Torque (Nm): 8
Cycle time (s): 296

Step 1: Fit fasteners

Step 2: Inspect incoming part

Step 3: Visual check

Step 4: Apply thread locker

Step 5: Fit fasteners

Step 6: Move to next station

Step 7: Record result