WORK INSTRUCTION

Document ID: DOC-0000696
Project: PRJ-014
Uploaded on: 2023-10-01
Uploaded by: user185
Export class: EAR99

Assembly of P-100557 at plant PLT03

Part Number: P-100557
Revision: A.1
Plant: PLT03
Station: ST-74
Torque (Nm): 20
Cycle time (s): 68

Step 1: Record result

Step 2: Inspect incoming part

Step 3: Visual check

Step 4: Apply thread locker

Step 5: Torque to specification

Step 6: Move to next station

Step 7: Fit fasteners

Step 8: Clean mating surface

Assembly of P-100308 at plant PLT02

Part Number: P-100308
Revision: A.1
Plant: PLT02
Station: ST-14
Torque (Nm): 2.5
Cycle time (s): 193

Step 1: Apply thread locker

Step 2: Inspect incoming part

Step 3: Visual check

Step 4: Torque to specification

Step 5: Clean mating surface

Step 6: Fit fasteners

Step 7: Inspect incoming part

Step 8: Fit fasteners