WORK INSTRUCTION

Document ID: DOC-0001043
Project: PRJ-039
Uploaded on: 2024-04-01
Uploaded by: user052
Export class: EAR99

Assembly of P-100542 at plant PLT03

Part Number: P-100542
Revision: B.1
Plant: PLT03
Station: ST-17
Torque (Nm): 5
Cycle time (s): 187

Step 1: Inspect incoming part

Step 2: Clean mating surface

Step 3: Fit fasteners

Step 4: Move to next station

Step 5: Apply thread locker

Assembly of P-100629 at plant PLT01

Part Number: P-100629
Revision: A.1
Plant: PLT01
Station: ST-31
Torque (Nm): 8
Cycle time (s): 58

Step 1: Move to next station

Step 2: Record result

Step 3: Move to next station

Step 4: Apply thread locker

Step 5: Visual check

Step 6: Inspect incoming part