WORK INSTRUCTION

Document ID: DOC-0001904
Project: PRJ-037
Uploaded on: 2025-05-04
Uploaded by: user132
Export class: EAR99

Assembly of P-102801 at plant PLT03

Part Number: P-102801
Revision: A.1
Plant: PLT03
Station: ST-85
Torque (Nm): 12
Cycle time (s): 187

Step 1: Record result

Step 2: Visual check

Step 3: Inspect incoming part

Step 4: Visual check

Step 5: Clean mating surface

Step 6: Inspect incoming part

Step 7: Inspect incoming part

Assembly of P-100001 at plant PLT01

Part Number: P-100001
Revision: B.1
Plant: PLT01
Station: ST-69
Torque (Nm): 20
Cycle time (s): 42

Step 1: Record result

Step 2: Fit fasteners

Step 3: Inspect incoming part

Step 4: Record result

Step 5: Fit fasteners

Step 6: Visual check

Step 7: Move to next station