WORK INSTRUCTION

Document ID: DOC-0002244
Project: PRJ-009
Uploaded on: 2025-10-05
Uploaded by: user178
Export class: EAR99

Assembly of P-103356 at plant PLT03

Part Number: P-103356
Revision: A.1
Plant: PLT03
Station: ST-68
Torque (Nm): 8
Cycle time (s): 74

Step 1: Move to next station

Step 2: Fit fasteners

Step 3: Clean mating surface

Step 4: Visual check

Step 5: Fit fasteners

Step 6: Apply thread locker

Step 7: Move to next station