WORK INSTRUCTION

Document ID: DOC-0002261
Project: PRJ-037
Uploaded on: 2025-10-15
Uploaded by: user008
Export class: EAR99

Assembly of P-102863 at plant PLT01

Part Number: P-102863
Revision: A.1
Plant: PLT01
Station: ST-70
Torque (Nm): 2.5
Cycle time (s): 44

Step 1: Inspect incoming part

Step 2: Move to next station

Step 3: Fit fasteners

Step 4: Visual check

Step 5: Fit fasteners

Step 6: Record result

Assembly of P-100662 at plant PLT01

Part Number: P-100662
Revision: C.1
Plant: PLT01
Station: ST-62
Torque (Nm): 12
Cycle time (s): 94

Step 1: Apply thread locker

Step 2: Visual check

Step 3: Apply thread locker

Step 4: Clean mating surface

Step 5: Inspect incoming part

Step 6: Visual check