WORK INSTRUCTION

Document ID: DOC-0002423
Project: PRJ-013
Uploaded on: 2025-12-31
Uploaded by: user027
Export class: EAR99

Assembly of P-102258 at plant PLT01

Part Number: P-102258
Revision: A.1
Plant: PLT01
Station: ST-89
Torque (Nm): 2.5
Cycle time (s): 79

Step 1: Inspect incoming part

Step 2: Torque to specification

Step 3: Move to next station

Step 4: Torque to specification

Step 5: Record result

Step 6: Torque to specification

Step 7: Fit fasteners

Step 8: Torque to specification

Assembly of P-102275 at plant PLT02

Part Number: P-102275
Revision: A.1
Plant: PLT02
Station: ST-34
Torque (Nm): 2.5
Cycle time (s): 293

Step 1: Clean mating surface

Step 2: Fit fasteners

Step 3: Apply thread locker

Step 4: Apply thread locker

Step 5: Clean mating surface

Step 6: Torque to specification