WORK INSTRUCTION

Document ID: DOC-0001997
Project: PRJ-011
Uploaded on: 2025-06-10
Uploaded by: user106
Export class: EAR99

Assembly of P-100950 at plant PLT02

Part Number: P-100950
Revision: B.1
Plant: PLT02
Station: ST-31
Torque (Nm): 2.5
Cycle time (s): 203

Step 1: Visual check

Step 2: Fit fasteners

Step 3: Move to next station

Step 4: Inspect incoming part

Step 5: Record result

Step 6: Move to next station

Step 7: Apply thread locker