EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000699
Project: PRJ-029
Uploaded on: 2023-10-02
Uploaded by: user095
Export class: ECCN-3A001

Assembly of P-100997 at plant PLT01

Part Number: P-100997
Revision: A.1
Plant: PLT01
Station: ST-68
Torque (Nm): 20
Cycle time (s): 160

Step 1: Apply thread locker

Step 2: Clean mating surface

Step 3: Visual check

Step 4: Fit fasteners

Step 5: Visual check

Step 6: Fit fasteners

Step 7: Inspect incoming part