EXPORT CONTROLLED - ECCN 3A001

WORK INSTRUCTION

Document ID: DOC-0000702
Project: PRJ-014
Uploaded on: 2023-10-04
Uploaded by: user164
Export class: ECCN-3A001

Assembly of P-100569 at plant PLT03

Part Number: P-100569
Revision: A.1
Plant: PLT03
Station: ST-87
Torque (Nm): 12
Cycle time (s): 222

Step 1: Record result

Step 2: Record result

Step 3: Torque to specification

Step 4: Fit fasteners

Step 5: Record result

Step 6: Inspect incoming part

Step 7: Record result

Assembly of P-100733 at plant PLT03

Part Number: P-100733
Revision: A.1
Plant: PLT03
Station: ST-14
Torque (Nm): 5
Cycle time (s): 271

Step 1: Clean mating surface

Step 2: Move to next station

Step 3: Visual check

Step 4: Move to next station

Step 5: Clean mating surface

Step 6: Visual check

Step 7: Clean mating surface

Step 8: Apply thread locker

Assembly of P-100774 at plant PLT02

Part Number: P-100774
Revision: A.1

Plant:	PLT02
Station:	ST-25
Torque (Nm):	5
Cycle time (s):	233

Step 1: Inspect incoming part

Step 2: Fit fasteners

Step 3: Fit fasteners

Step 4: Fit fasteners

Step 5: Apply thread locker

Step 6: Apply thread locker