WORK INSTRUCTION

Document ID: DOC-0000791
Project: PRJ-031
Uploaded on: 2023-11-22
Uploaded by: user004
Export class: EAR99

Assembly of P-100801 at plant PLT01

Part Number: P-100801
Revision: A.1
Plant: PLT01
Station: ST-98
Torque (Nm): 8
Cycle time (s): 100

Step 1: Clean mating surface

Step 2: Inspect incoming part

Step 3: Inspect incoming part

Step 4: Record result

Step 5: Fit fasteners

Step 6: Move to next station

Step 7: Fit fasteners

Step 8: Torque to specification

Assembly of P-100728 at plant PLT01

Part Number: P-100728
Revision: A.1
Plant: PLT01
Station: ST-69
Torque (Nm): 5
Cycle time (s): 149

Step 1: Inspect incoming part

Step 2: Inspect incoming part

Step 3: Move to next station

Step 4: Inspect incoming part

Step 5: Torque to specification

Step 6: Apply thread locker

Step 7: Record result

Step 8: Record result