RCS07 | Morning Quiz - Answer Key

CTS Cohort 6 | CTS Day 15 | 2026-07-29 | 10:00 AM-3:00 PM | 6 students

Integrated Wall Build: Correct, Complete, Prove

1. What is a punch list?

A documented list of incomplete, defective, or unverified items requiring action.

2. What should a useful punch item include?

Location, expected condition, observed condition, owner/action, and verification result.

3. What is rework?

Work performed to correct a nonconforming result.

4. What is traceability?

The ability to connect a result to its process, inspection, evidence, and responsible action.

5. Why inspect subsystems before the whole wall?

It isolates problems and confirms each system before integration.

6. What energy rule remains active during correction?

No energized student work; isolate and verify before electrical work.

7. What four photo types support strong evidence?

Overall, detail, test setup, and corrected result.

8. Should unresolved items be hidden during handoff?

No; they must be clearly documented.

9. What proves a correction worked?

A defined retest or reinspection with recorded evidence.

10. When is a wall ready for handoff?

When acceptance criteria are met or remaining exceptions are explicitly documented and approved.

Scoring guidance

One point per item. Accept technically equivalent wording. Use errors to reteach before lab release. Safety-boundary errors must be corrected explicitly before the student begins the related task.