

Permit to Work Procedure

Hannah Weber · 26 February 2026 · HSE-PRO-0007

1. When a permit is required

Work type	Permit
Work on or near HV equipment (> 1 kV)	Electrical permit (HV safety rules) + isolation certificate
Work on LV systems requiring isolation	Electrical isolation permit (LOTO)
Hot work (welding, grinding, cutting) outside a workshop	Hot work permit
Entry into confined spaces (hub, blade, monopile, tanks)	Confined space permit
Work at height outside permanent protection	General work permit with rescue plan
Non-routine lifting operations	Lift plan + general work permit
Excavation near cables	Excavation permit + cable avoidance survey

2. Roles

- **Issuer** – authorised person who controls the site or system (e.g. site manager, Senior Authorised Person HV).
- **Receiver** – competent person who leads the work team and accepts the permit.
- **Isolating authority** – performs and verifies isolations.
- **Control room** – logs permits on its sites and blocks remote operation of isolated equipment.

3. Permit life cycle

1. Request at least 24 h in advance (except emergencies).
2. Risk assessment and method statement attached.
3. Isolation performed and verified; locks and tags applied.
4. Permit issued and explained on site, signed by issuer and receiver.
5. Work carried out; permit displayed at the work location.
6. Hand-back: work complete, area safe, isolations removed, permit closed.

4. Contractors

Contractors with their own permit system (e.g. O&M contractors, vessel operators) may use it if it has been reviewed by Weyland HSE and the interface is described in a bridging document.

5. Monitoring

Site managers audit at least 5 permits per month; HSE audits permit systems annually. Permit audit findings are reported in the monthly HSE report.