Solid States Electronics a.k.a. fresh new history, part 2

Mario Alberto García-Ramíez, PhD

MU-JTSU JI

May 22, 2017

Introduction

Doping the semiconductor structure


Semiconductor advantage is the property to be modified through the injection of well controlled impurities

- Semiconductor advantage is the property to be modified through the injection of well controlled impurities
- ► The process is known as impurity doping or just doping

- Semiconductor advantage is the property to be modified through the injection of well controlled impurities
- ► The process is known as impurity doping or just doping
- Doping allow us to control the resistivity (energy bands separation)

- Semiconductor advantage is the property to be modified through the injection of well controlled impurities
- ► The process is known as impurity doping or just doping
- Doping allow us to control the resistivity (energy bands separation)
- Impurities allow us to control if the electrons or holes will control the resistivity of the material.

- Semiconductor advantage is the property to be modified through the injection of well controlled impurities
- ▶ The process is known as impurity doping or just doping
- Doping allow us to control the resistivity (energy bands separation)
- Impurities allow us to control if the electrons or holes will control the resistivity of the material.



Impurities in Silicon: Donor

- ▶ Donor for Si are from group V, it means 5 valence band electrons
- ► The most common elements used are: Phosphorus, arsenic and antimony
- ▶ While a donor is immersed within the Si lattice, 4 e⁻ fill the covalent bond structure
- ▶ It requires very little thermal energy to free the extra electron for conduction
- ► Each donor that is ionized by giving an e⁻, will produce a net charge of +q


▶ In contrast, acceptor impurities come from group III

- ▶ In contrast, acceptor impurities come from group III
- Main primary acceptor is boron

- In contrast, acceptor impurities come from group III
- Main primary acceptor is boron
- ▶ Due to lack of enough electrons, a hole is always present and it move freely over the lattice

- In contrast, acceptor impurities come from group III
- Main primary acceptor is boron
- ▶ Due to lack of enough electrons, a hole is always present and it move freely over the lattice
- ► Each acceptor that is ionized, will produce a net charge of -q

- In contrast, acceptor impurities come from group III
- Main primary acceptor is boron
- ▶ Due to lack of enough electrons, a hole is always present and it move freely over the lattice
- ► Each acceptor that is ionized, will produce a net charge of -q



► From this point on, whole analysis are not in equilibrium, we already doped it with impurities

- ► From this point on, whole analysis are not in equilibrium, we already doped it with impurities
- If n>p, material is called n-type. In contrast, if n<p, it is called p-type

- ► From this point on, whole analysis are not in equilibrium, we already doped it with impurities
- If n>p, material is called n-type. In contrast, if n<p, it is called p-type
- ► Carrier with lager population is called majority carrier and with smaller population it is called minority carrier

- From this point on, whole analysis are not in equilibrium, we already doped it with impurities
- If n>p, material is called n-type. In contrast, if n<p, it is called p-type
- ► Carrier with lager population is called majority carrier and with smaller population it is called minority carrier
- ► To get accurate calculations for h⁺ and e⁻ densities, we require to have a tight control of impurity concentrations

- From this point on, whole analysis are not in equilibrium, we already doped it with impurities
- If n>p, material is called n-type. In contrast, if n<p, it is called p-type
- ► Carrier with lager population is called majority carrier and with smaller population it is called minority carrier
- ► To get accurate calculations for h⁺ and e⁻ densities, we require to have a tight control of impurity concentrations
- $ightharpoonup N_D = donor impurities concentration atoms/cm³$

- ► From this point on, whole analysis are not in equilibrium, we already doped it with impurities
- If n>p, material is called n-type. In contrast, if n<p, it is called p-type
- ► Carrier with lager population is called majority carrier and with smaller population it is called minority carrier
- ► To get accurate calculations for h⁺ and e⁻ densities, we require to have a tight control of impurity concentrations
- $ightharpoonup N_D = donor impurities concentration atoms/cm³$
- $ightharpoonup N_A = acceptor impurities concentration atoms/cm³$

- ► From this point on, whole analysis are not in equilibrium, we already doped it with impurities
- If n>p, material is called n-type. In contrast, if n<p, it is called p-type
- ► Carrier with lager population is called majority carrier and with smaller population it is called minority carrier
- ► To get accurate calculations for h⁺ and e⁻ densities, we require to have a tight control of impurity concentrations
- $ightharpoonup N_D = donor impurities concentration atoms/cm³$
- $ightharpoonup N_A = acceptor impurities concentration atoms/cm^3$
- ▶ On top of that, it is required to have a semiconductor charge neutral. Ergo, whole charges within it must be zero.

- From this point on, whole analysis are not in equilibrium, we already doped it with impurities
- If n>p, material is called n-type. In contrast, if n<p, it is called p-type
- ► Carrier with lager population is called majority carrier and with smaller population it is called minority carrier
- ► To get accurate calculations for h⁺ and e⁻ densities, we require to have a tight control of impurity concentrations
- $ightharpoonup N_D = donor impurities concentration atoms/cm³$
- $ightharpoonup N_A = acceptor impurities concentration atoms/cm³$
- ▶ On top of that, it is required to have a semiconductor charge neutral. Ergo, whole charges within it must be zero.
- Charge neutrality requires:

$$q(N_d + p - N_A - n) = 0$$



n-type material $(N_D > N_A)$

By considering that $pn=n_i^2$, we have

$$n^2 - (N_D - N_A)n - n_i^2 = 0$$

Solving for n

$$n = \frac{(N_D - N_A) + \sqrt{(N_D - N_A)^2 + 4n_i^2}}{2}$$

also,

$$p=\frac{n_i^2}{n}$$

Nevertheless, in reality we require to be practical so, $(N_D - N_A) >> 2n_i$ and $n \approx (N_D - N_A)$, ergo $n = N_D > N_A$

p-type material $(N_A > N_D)$

$$\rho = \frac{(N_A - N_D) + \sqrt{(N_A - N_D)^2 + 4n_i^2}}{2}$$

also,

$$p=\frac{n_i^2}{n}$$


As Previously state, in reality we require to be practical so, $(N_A - N_D) >> 2n_i$ and $n \approx (N_A - N_D)$, ergo $p = N_A > N_D$

▶ By doping Si, the mobility is reduced due to atoms have slightly different sizes

- By doping Si, the mobility is reduced due to atoms have slightly different sizes
- ► As impurities are ionized and are localized charge regions that were not available in the original crystal.

- By doping Si, the mobility is reduced due to atoms have slightly different sizes
- ► As impurities are ionized and are localized charge regions that were not available in the original crystal.
- ▶ Due to those effects, e⁻ and h⁺ scatter and move freely through the lattice to reduce the mobility.

- By doping Si, the mobility is reduced due to atoms have slightly different sizes
- ▶ As impurities are ionized and are localized charge regions that were not available in the original crystal.
- ▶ Due to those effects, e⁻ and h⁺ scatter and move freely through the lattice to reduce the mobility.



▶ Doping determines if the material is either n- or p-type

- ▶ Doping determines if the material is either n- or p-type
- ► The major carrier concentration drives the conductivity of the material this is why

- Doping determines if the material is either n- or p-type
- ► The major carrier concentration drives the conductivity of the material this is why
- $\sigma \approx q \mu_n n \approx (N_D N_A)$ for n-type
- $\sigma \approx q \mu_p n \approx (N_A N_D)$ for p-type

- Doping determines if the material is either n- or p-type
- ► The major carrier concentration drives the conductivity of the material this is why
- $\sigma \approx q \mu_n n \approx (N_D N_A)$ for n-type
- $\sigma \approx q \mu_p n \approx (N_A N_D)$ for p-type
- Resistivity is defined as

•

$$\rho = \frac{1}{\sigma}$$

► e⁻ and h⁺ are driven by N_D & N_A, we assumed that distribution is uniform, which is wrong

- ▶ e⁻ and h⁺ are driven by N_D & N_A , we assumed that distribution is uniform, which is wrong
- While doping, there will be gradient concentration for e[−] and h⁺

- ▶ e⁻ and h⁺ are driven by N_D & N_A, we assumed that distribution is uniform, which is wrong
- ▶ While doping, there will be gradient concentration for e⁻ and h⁺
- ► As a consequence, the free carrier gradients generates a second current flow mechanism known as diffusion


- ▶ e⁻ and h⁺ are driven by N_D & N_A , we assumed that distribution is uniform, which is wrong
- ▶ While doping, there will be gradient concentration for e⁻ and h⁺
- ➤ As a consequence, the free carrier gradients generates a second current flow mechanism known as diffusion
- ▶ Free carriers move from regions with high to low concentration

- ▶ e⁻ and h⁺ are driven by N_D & N_A, we assumed that distribution is uniform, which is wrong
- ▶ While doping, there will be gradient concentration for e⁻ and h⁺
- ➤ As a consequence, the free carrier gradients generates a second current flow mechanism known as diffusion
- ► Free carriers move from regions with high to low concentration
- Diffusion current densities are proportional to the negative of the carrierr gradient

- ▶ e⁻ and h⁺ are driven by N_D & N_A , we assumed that distribution is uniform, which is wrong
- ▶ While doping, there will be gradient concentration for e⁻ and h⁺
- ▶ As a consequence, the free carrier gradients generates a second current flow mechanism known as diffusion
- Free carriers move from regions with high to low concentration
- Diffusion current densities are proportional to the negative of the carrierr gradient

$$j_p^{diff} = +qD_p(-\frac{\partial p}{\partial x}) = -qD_p\frac{\partial p}{\partial x}$$

$$j_n^{diff} = -qD_n(-\frac{\partial p}{\partial x}) = +qD_n\frac{\partial n}{\partial x}$$



Proportionality constants D_p & D_n are e^- and h^+ diffusivities (cm²/s). Both diffusivity and mobility are related by Einstein's relationship

$$\frac{D_n}{\mu_n} = \frac{kT}{q} = \frac{D_p}{\mu_p}$$

Total Currents

Currents within a semiconductor have drift and diffusion components. e^- and h^+ densities j_n^T and j_p^T can be found if a few parameter are included such as

$$j_n^T = q\mu_n nE + qD_n \frac{\partial n}{\partial x}$$

$$j_p^T = q\mu_p pE + qD_p \frac{\partial p}{\partial x}$$

By using the Einstein's relationships

$$j_n^T = q\mu_n n(E + V_T \frac{1}{n} \frac{\partial n}{\partial x})$$

$$j_p^T = q\mu_p p(E + V_T \frac{1}{p} \frac{\partial p}{\partial x})$$

Energy Band Model

While Si is doped by either acceptor or donor, the band energy changes. The donors introduce a localized energy level within the band gap know as donor energy level E_D . For phosphorus ≈ 0.045 eV, it takes a bit of thermal energy to access to the conduction band.

As for doped with acceptors N_A , it is created an acceptor energy level E_A close to the valence band. For boron it is 0.044 eV. It requires a bit amount of energy to move electrons from the valence in to the acceptor energy band.

It contains both kind of impurities. In here, there are more donors. e^- search for the lowest state available filling all acceptors. Free e^- population is $n=N_D-N_A$



Figure 2.13 Donor level with activation energy $(E_C - E_D)$. This f gure corresponds to the bond model of Fig. 2.6.




Figure 2.14 Acceptor level with activation energy $(E_A - E_V)$. This f gure corresponds to the bond model of Fig. 2.7(b).



Figure 2.15 Compensated semiconductor containing both donor and acceptor atoms with $N_D > N_A$.

Fabrication of Simple Structures



Fabrication of Simple Structures

