

- To update the aliquot the user will click on the 'Update' link next to it's corresponding Aliquot ID in the AQID column.
- This procedure is also how a user will check an aliquot back into the box.
- The process is sped up by knowing the Aliquot ID



• All fields of an Aliquot can be updated on this page.

• Required Fields have an * after the label and if left blank a widget will notify the user and the submission will not go through.



- Note that the Aliquot ID(Aqid) <u>cannot</u> be updated.
- If the user entered an incorrect Aqid then they must <u>add a new</u> aliquot with the correct Aqid and <u>dispose of the incorrect</u> Aqid.