TICO PRO-SPOTTER				
S/N:			BATTERY DISCONNECT KIT (3 BATTERY) QSB	71366
ITEM	PART #	QTY/M	DESCRIPTION	TASK
IIEIVI	PARI#	QTT/IVI	DESCRIPTION	IASK
	71366-B1	REF	BATTERY DISCONNECT KIT (3 BATTERY) QSB	
	71300 B1	IVEI	DATTERT DISCONNECTRIT (5 DATTERT) Q3D	
1	40303	1	BATTERY DISCONNECT SWITCH	7
2	40303-1	1	SWITCH PLATE - ON/OFF	7
3	91166	1	BRACKET - BATTERY DISCONNECT SWITCH	7
4	82371	2	BOLT - 5/16-18 X 1 LG - BRACKET TO BATTERY BOX	7
5	85112	4	WASHER 5/16	7
6	85035	2	NUT-LOCK 5/16-18	7
7	91583	1	CABLE 3/0 POS BATTERY TO DISC SWITCH - 26"	7
8	91583	1	CABLE 3/0 POS BATTERY TO DISC SWITCH - 26 CABLE 3/0 POS PDC TO DISC SWITCH - 38"	7
ن د	31130	1	CUBER 2/0 LOS LOS DISC 24411CH - 20	
REV	DATE	BY		SHEEET
В	10/26/12	HK		1 OF 1

