TICO PRO-SPOTTER				
S/N:			BATTERY DISCONNECT KIT (3 BATTERY) QSB	71750
		L 0=1/20		
ITEM	PART #	QTY/M	DESCRIPTION	TASK
	7175041	DEE	DATTERY DISCONNECT WIT /2 DATTERY) OCD	
	71750A1	REF	BATTERY DISCONNECT KIT (3 BATTERY) QSB	
1	91198	1	BRACKET - BATTERY DISCONNECT SWITCH	7
2	42097	1	BATTERY DISCONNECT SWITCH	7
3	82371	2	BOLT - 5/16-18 X 1 LG - BRACKET TO BATTERY BOX	7
4	85112	4	WASHER 5/16	7
5	85024	2	NUT-LOCK 5/16-18	7
6	42097	2	LOCKOUT KIT FOR DISCONNECT SWITCH	7
7	42135	1	DECAL LOCKOUT	7
8	91583	1	CABLE 3/0 POS BATTERY TO DISC SWITCH - 26"	7
9	91138	1	CABLE 3/0 POS PDC TO DISC SWITCH - 38"	7
DEV/	DATE	DV		CHEFF
REV	DATE	BY		SHEEET
Α	10/26/12	HK		1 OF 1

