

SigmaStar Camera I2C User Guide

Version 0.1




© 2020 SigmaStar Technology Corp. All rights reserved.

SigmaStar Technology makes no representations or warranties including, for example but not limited to, warranties of merchantability, fitness for a particular purpose, non-infringement of any intellectual property right or the accuracy or completeness of this document, and reserves the right to make changes without further notice to any products herein to improve reliability, function or design. No responsibility is assumed by SigmaStar Technology arising out of the application or use of any product or circuit described herein; neither does it convey any license under its patent rights, nor the rights of others.

SigmaStar is a trademark of SigmaStar Technology Corp. Other trademarks or names herein are only for identification purposes only and owned by their respective owners.

SigmaStar SSC335 Series





REVISION HISTORY

Revision No.	Description	Date
0.1	Initial release	12/18/2019

SigmaStar SSC335 Series

I2C User Guide



TABLE OF CONTENTS

Sigm**Star**

RE\	REVISION HISTORYi				
	1. OVERVIEW				
	1.1. General Description				
	USING I2C.				
	2.1 I2C Read/Write	-			





1. OVERVIEW

1.1. General Description

I2C Group	SCL	SDA	DEV
HW I2C group0	PAD_I2C0_SCL	PAD_I2C0_SDA	/dev/i2c-0
HW I2C group1	PAD_I2C1_SCL	PAD_I2C1_SDA	/dev/i2c-1,

As illustrated in the above table, there are two groups of HW I2C. The first group corresponds to PAD_I2C0_SCL/PAD_I2C0_SDA and the device node /dev/i2c-0. The second group corresponds to PAD_I2C1_SCL/PAD_I2C1_SDA and the device node /dev/i2c-1.

If not all of the two groups of I2C are used, refer to the definition "#define HAL_HWI2C_PORTS 2" in mhal_iic.h and the I2C device node in infinity6b0.dtsi. Normally, the definition in i2c-group = <0> denotes the corresponding device node.

```
i2c0@0{
   compatible = "mstar,i2c";
   status = "ok";
   reg = <0x1F226800 0x200>,<0x1F204c00 0x200>,<0x1F206600 0x200>;
   //clocks = <&CLK_miic0>;
   i2c-group = <0>;
   i2c-dma = <0>;
   /*
        * padmux: 1 -> PAD_I2C0_SCL, PAD_I2C0_SDA
        */
   i2c-padmux = <1>;
};
```

The example illustrated below is given based on the first I2C group. For usage of the remaining groups, refer to the first group directly.



2. USING I2C

2.1. I2C Read/Write

Below is an example of I2C read/write via standard ms_i2c_xfer function.

```
#include <stdio.h>
#include linux/types.h>
#include <stdlib.h>
#include <fcntl.h>
#include <unistd.h>
#include <sys/types.h>
#include <sys/ioctl.h>
#include <errno.h>
#include <assert.h>
#include <string.h>
#include ux/i2c.h>
#include ux/i2c-dev.h>
#define FILE_NAME "/dev/i2c-0"
static int i2c_write(int fd,unsigned char slave_addr, unsigned char reg_addr, unsigned char value)
    unsigned char outbuf[2];
    struct i2c_rdwr_ioctl_data packets;
    struct i2c_msg messages[1];
    messages[0].addr = slave_addr;
    messages[0].flags = 0;
    messages[0].len
                       = sizeof(outbuf);
    messages[0].buf
                       = outbuf;
    /* The first byte indicates which register we 'll write */
    outbuf[0] = reg_addr;
    /*
     * The second byte indicates the value to write. Note that for many
     * devices, we can write multiple, sequential registers at once by
     * simply making outbuf bigger.
     */
```



```
outbuf[1] = value;
    /* Transfer the i2c packets to the kernel and verify it worked */
    packets.msgs = messages;
    packets.nmsqs = 1;
    if(ioctl(fd, I2C_RDWR, &packets) < 0)
         perror("Unable to send data");
        return 1;
    }
    return 0;
}
static int i2c_read(int fd, unsigned char slave_addr, unsigned char reg_addr, unsigned char *value)
    unsigned char inbuf, outbuf;
    struct i2c_rdwr_ioctl_data packets;
    struct i2c_msg messages[2];
     * In order to read a register, we first do a "dummy write" by writing
     * 0 bytes to the register we want to read from. This is similar to
     * the packet in set_i2c_register, except it 's 1 byte rather than 2.
     */
    outbuf = reg addr;
    messages[0].addr = slave addr;
    messages[0].flags = 0;
                       = sizeof(outbuf);
    messages[0].len
    messages[0].buf
                        = &outbuf;
    /* The data will get returned in this structure */
    messages[1].addr = slave addr;
    messages[1].flags = I2C_M_RD/* | I2C_M_NOSTART*/;
    messages[1].len = sizeof(inbuf);
    messages[1].buf
                        = &inbuf;
    /* Send the request to the kernel and get the result back */
    packets.msgs
                        = messages;
    packets.nmsqs
                        = 2;
    if(ioctl(fd, I2C_RDWR, &packets) < 0)
    {
         perror("Unable to send data");
         return 1;
```



```
*value = inbuf;
    return 0;
}
int main(int argc, char **argv)
{
    int fd;
    unsigned int slave_addr=0, reg_addr=0, value = 0;
    if (argc < 4){
         printf("Usage:\n%s r[w] start_addr reg_addr [value]\n",argv[0]);
         return 0;
    }
    fd = open(FILE_NAME, O_RDWR);
    if (!fd)
    {
         printf("can not open file %s\n", FILE_NAME);
         return 0;
    }
    sscanf(argv[2], "%x", &slave_addr);
    sscanf(argv[3], "%x", &reg_addr);
    if(!strcmp(argv[1],"r"))
    {
         i2c_read(fd, slave_addr, reg_addr, (unsigned char*)&value);
    else if(argc>4&&!strcmp(argv[1],"w"))
         sscanf(argv[4], "%x", &value);
         i2c_write(fd, slave_addr, reg_addr, value);
    }
    close(fd);
    return 0;
}
```