
https://github.com/teaksoon/lmaewapm

#### WORKING MEMORY



To use the **WORKING MEMORY (SRAM)** in our PROGRAM, we will need "Reserve in BLOCKS of multiple BITS". Each "BLOCK" of "Reserved MEMORY" is commonly known as "VARIABLE"

## The C-Language Keywords and Symbols

Keywords		Symbols					
MEMORY	CONTROL	CONTROL	LOGIC		MATH	BIT OF	•
01.void	21.return	#	==		*	1	
02.char	22.if	< >	! =		용	&	
03.int	23.else	//	<		/	^	
04.short	24.switch	/* */	>		+	~	
05.long	25.case	( )	<= >=		_	<< >>	
06.float	26.default	{ }	/-			//	
07.double	27.while	;	& &				
08.signed	28.do	,	11				
09.unsigned	29.for	u					
10.struct	30.break	•	!				
11.union	31.continue	=					
12.enum	32.goto	[ ]					
13.const		:					
14.volatile		?					
15.auto							
16.extern		\					
17.static							
18.register		MEMORY					
19.typedef		&					
20.sizeof		*					

Out of the Total 32 C-Language Keywords
20 Keywords are used to just handle the WORKING MEMORY

- The  $first\ 18$  Keywords, are used exclusively for creating/declaring VARIABLES with its various properties and features
- **19.typedef -** utility for us to create a new DATATYPE from the existing DATATYPE
- 20.sizeof utility for us to find out the number of BYTE used in any VARIABLE

That leaves us just 12 Keywords for all the other things. This is how important the WORKING MEMORY is to C-Language

## ATMEGA328/Arduino Uno - MEMORY - VARIABLE - PART 3

https://github.com/teaksoon/lmaewapm

Lets look at the **20 C-Language Keywords** that we use to manipulate the WORKING MEMORY

### ( PART 3 )

The remaining 4 C-Language Keywords for MEMORY (for simple PROGRAM we probably will not use them )

#### BASIC DATATYPE

these are the BASIC DATATYPE used in C-Language

**02.char** (8-BIT)

**03.int** (16-BIT for ATMEGA328P) - can be different for others

**04.short** (16-BIT)

**05.long** (32-BIT)

**06.float** (32-BIT)

**07.double** (32-BIT for ATMEGA328P) - can be different for others

**08.signed** (Stored number can have **Positive** and **Negative Numbers**)

09.unsigned (Stored number can have Positive Numbers Only)

#### SPECIAL DATATYPE

these are extensions to the BASIC DATATYPE

10.struct (Multiple members of various DATATYPE)

11.union (Multiple members of various DATATYPE sharing the same the MEMORY)

**12.enum** (Multiple members of 16-BIT auto-increment number)

#### PROPERTIES

also known as type qualifiers

13.const (Variable with Initial Data assigned that cannot be changed)

14.volatile (Prevent the Compiler from automatic Optimizing of MEMORY)

#### **FEATURES**

these are Storage Classes of a Variable

**15.auto** (DATATYPE from the Initial Data assigned)

**16.extern** (Variable declaration is stored in a different file)

17. static (Variable with Initial Data assigned just once, retains value)

18.register (Use CPU MEMORY instead of WORKING MEMORY) \*compiler decides

#### DATATYPE UTILITIES

19.typedef (Create a new DATATYPE from the existing DATATYPE)

20.sizeof (Find out the number of BYTE in any Variable) : 1 BYTE = 8 BITS

#### VOID

# **01.void** (Empty DATATYPE)

- Most commonly used as function return  ${\tt DATATYPE}$  when a function returns nothing
- Less commonly used as parameter(optional) when functions that does not have any parameters
- Also used as memory pointers Variable to unknown DATATYPE

```
ATMEGA328/Arduino Uno - MEMORY - VARIABLE - PART 3
```

https://github.com/teaksoon/lmaewapm

15.auto

```
BASIC DATATYPE: Create/Declare Variable with "auto" Keyword
Part1: "auto" Keyword
Part2:name
Part3: value
Part1: "auto" Keyword followed by space
   Part2:name, name followed by an equal sign =
            Part3: value, followed by a semi-colon;
auto name = value;
Example PROGRAM:
Arduino IDE|Save PROGRAM as: c_variable_auto
Enter codes below and upload. Use the Serial Monitor to see results
auto counter = 0;
auto temp = 'A';
auto millis_timer = millis();
void setup(){
  Serial.begin(9600); Serial.print("\nSerial Monitor(9600)...\n");
  Serial.print("\nData stored in variable counter = ");
  Serial.print(counter);
  Serial.print("\nNumber of BITS used by counter = ");
  Serial.print(sizeof(counter)*8);
  Serial.print("\n\nData stored in variable temp = ");
 Serial.print(temp);
Serial.print("\nNumber of BITS used by temp = ");
  Serial.print(sizeof(temp)*8);
  Serial.print("\n\nData stored in variable millis_timer = ");
 Serial.print(millis_timer);
  Serial.print("\nNumber of BITS used by millis_timer = ");
  Serial.print(sizeof(millis_timer)*8);
void loop(){}
NOTE: When we use "auto" we do not need to specify the DATATYPE. However, an
initial value must be provided during Variable declaration. Based on the
initial value assigned, a suitable DATATYPE is chosen.
In this example PROGRAM:
- temp variable is assigned with 'A', which is a char DATATYPE. Therefore it
is 1-BYTE
- millis_timer variable is assigned with value return from millis()
function, which is "long" DATATYPE. Therefore it is 4-BYTE
"auto" Keyword is seldom used because it can cause confusion in our PROGRAM
For example: auto counter = 0, in this case auto uses 2-BYTE which is an
"int". "long", "char" and "short" are also valid DATATYPE
C-Language Keyword
```

(DATATYPE from the Initial Data assigned)

```
ATMEGA328/Arduino Uno - MEMORY - VARIABLE - PART 3
https://github.com/teaksoon/lmaewapm
```

```
BASIC DATATYPE: Create/Declare Variable with "extern" Keyword
Part1: "extern" Keyword
Part3: value

Part1: "extern" Keyword followed by space
Part2: datatype, followed by space
Part3: name, followed by a semi-colon;

extern datatype name;
```

Or with an initial value

# extern datatype name = 0;

## Example PROGRAM:

Arduino IDE|Save PROGRAM as: c\_variable\_extern Enter codes below


```
extern int counter;

void setup() {
   counter = 0;
   Serial.begin(9600);Serial.print("\nSerial Monitor(9600)...\n");

   Serial.print("\nData stored in variable counter = ");
   Serial.print(counter);
   Serial.print("\nNumber of BITS used by counter = ");
   Serial.print(sizeof(counter)*8);

}

void loop() {}
```



NOTE: This is exactly same like the regular Variable Declaration. Usage of the Variable from this Declaration is also the same.

It is just telling the Compiler Software that this Variable is declared somewhere else, in another file. In this example, the counter variable is declared in another file name "var\_extern.cpp". Try comment off the extern and see what happens

# C-Language Keyword

**16.extern** (Variable declaration is stored in a different file)

```
ATMEGA328/Arduino Uno - MEMORY - VARIABLE - PART 3
```

Part2:datatype, followed by space

https://github.com/teaksoon/lmaewapm

```
BASIC DATATYPE: Create/Declare Variable with "volatile" Keyword
Part1:"volatile" Keyword
Part3:value

Part1:"volatile" Keyword followed by space
```

Part3:name, followed by a semi-colon;

# volatile datatype name;

Or with an initial value

# volatile datatype name = 0;

## Example PROGRAM:

```
Arduino IDE|Save PROGRAM as: c_variable_volatile
Enter codes below and upload. Use the Serial Monitor to see results
```

```
volatile const int data = 5; // try change these two to see impact
// const int data = 5;

void setup() {
  int *ptr = (int*) &data;

  Serial.begin(9600); Serial.print("\nSerial Monitor(9600)...\n");

  Serial.print("\nInitial value of data = "); Serial.print(data);

  *ptr = 20; // Without "volatile" Compiler optimize this (getting rid of this code)

  Serial.print("\nNew value of data = "); Serial.print(data);
}

void loop(){}
```

NOTE: This is exactly same like the regular Variable Declaration. Usage of the Variable from this Declaration is also the same. The difference is, with the "volatile" Keyword, we are asking the "Compiler Software" not to do any optimizing on the Variable

Optimizing activity normally get rid of "useless" codes, like the one in this example.

In this example PROGRAM: The optimizer decides that the code "\*ptr=20" is "useless", therefore it is "removed". By putting a "volatile" Keyword on Variable "data" the optimizer will not touch "\*ptr=20" because \*ptr is related to "data" variable. This PROGRAM is just to demonstrate what the Optimizer can do, there is no reason for us to code like the above

However there are a few place where the Optimizer can interfere, thats where we use our "volatile" Keyword

- global variables that will be modified by interrupt
- global variables used in RTOS
- Variables for registers with pointers access

### C-Langugae Keyword

17.volatile (Prevent the Compiler from automatic Optimizing of MEMORY)

```
ATMEGA328/Arduino Uno - MEMORY - VARIABLE - PART 3
```

https://github.com/teaksoon/lmaewapm

```
BASIC DATATYPE: Create/Declare Variable with "register" Keyword
Part1: "register" Keyword
Part2:name
Part3:value
```

# register datatype name;

Or with an initial value

# register datatype name = 0;

### Example PROGRAM:

Arduino IDE|Save PROGRAM as: c\_variable\_register
Enter codes below and upload. Use the Serial Monitor to see results

```
register int counter = 0;

void setup(){
    Serial.begin(9600); Serial.print("\nSerial Monitor(9600)...\n");

    Serial.print("\n\nData stored in variable counter = ");
    Serial.print(counter);
    Serial.print("\nNumber of BITS used by counter = ");
    Serial.print(sizeof(counter)*8);
}

void loop(){}
```

NOTE: This is exactly same like the regular Variable Declaration. Usage of the Variable from this Declaration is also the same.

The difference is, with the "register" Keyword, we are asking the "Compiler Software" to use the CPU Memory instead of the SRAM Memory. CPU Memory has higher speed than SRAM Memory.

Normally, the "Compiler Software" will already do it for us. So this "register" Keyword is not really needed

## C-Language Keyword

18.register (Use CPU MEMORY instead of WORKING MEMORY) \*compiler decides