

Group	Component	# of wires in group	Color designation	Notes
1	RoArm	3	R: TX	The red wire goes from RX on the RoArm to TX on the PCB
			B: GND	
			Y: RX	
2	Joystick X-axis	3	R: VCC	
			B: GND	
			Y: A3	
3	Joystick Y-axis	3	R: VCC	
			B: GND	
			Y: A2	
4	Joystick Z-axis	3	R: VCC	
			B: GND	
			Y: A4	
5	Joystick Button	2	R: A5	
			B: GND	
6	E-Stop	2	R: VCC	
			B: GND	
7	E-Stop	2	R: 14	
			B: GND	
8	Mode button	2	R: 32	
			B: GND	
9	Screen	3	R: VCC	I04 acts as reset
			B: GND	
			Y: I04	
10	Screen	2	R: 13	
			B: 12	
11	Screen	2	R: SCK	
			B: MOSI	