


# PFUMA BS-01 — Base Station Wiring Diagram

Real components, real pin-level wiring — matches hardware/HARDWARE\_DESIGN.md §2.3 exactly.



**Build notes:** Same wiring conventions as CN-01. The base station has no battery/solar/sensor chain — it runs off a 12V DC adapter through a buck converter, and drives an OLED status display plus 4 indicator LEDs instead of body sensors.