
RESCUE STRUTS Parts List

(A - 368A049, B - 368A050, C - 368A051, D - 368A052, E - 368A053, E457 - 368A054, F - 368A055, F711 - 368A056)



AIRSHORE

| ITEM | PART# | DECSRIPTION |
|----------|------------|---------------------|
| 1 | PAR-00A1 | A PISTON |
| <u> </u> | PAR-00B1 | B PISTON |
| | PAR-00C1 | C PISTON |
| | PAR-00D1 | D PISTON |
| | PAR-00E1 | E PISTON |
| | PAR-4571 | E457 PISTON |
| | PAR-00F1 | F PISTON |
| | PAR-F711 | F711 PISTON |
| 2 | PAS-0009 | RUBBER CUP |
| 3 | PAS-0010 | WASHER |
| 4 | PAS-0011 | HEX HEAD BOLT |
| 5 | PAR-QC-RCS | SMALL RETAINER |
| 6 | PAR-QC-RCL | LARGE RETAINER |
| 7 | PAR-QC-RK | KNOB |
| | PAR-QC-KK | |
| 8 | PAR-QC-SP | STRIKER SPRING |
| | | |
| 10 | PAR-QC-TI | THREADED INSERT |
| 11 | 224A026 | INCLINE COLLAR |
| 12 | 215A186 | SOCKET HEAD SCREW |
| 13 | 113A010 | EYEBOLT |
| 14 | 107A039 | A BARREL |
| | 107A040 | B BARREL |
| | 107A041 | C BARREL |
| | 107A042 | D BARREL |
| | 107A043 | E BARREL |
| | 107A044 | E457 BARREL |
| | 107A045 | F BARREL |
| | 107A046 | F711 BARREL |
| 15 | PAR-0030 | FLAT HEAD SCREW |
| 16 | PAR-0028 | O-RING |
| 17 | PAR-0025 | END CAP |
| 18 | PAR-0013 | AIR NIPPLE |
| 19 | | |
| 20 | K2-500N | HEX NUT |
| 21 | 404A126 | T-HANDLE |
| 22 | PAR-SSLC | LANYARD CONNECTOR |
| 23 | PAR-0026 | QUICK CLIP |
| 24 | 189A077 | PIN w/LANYARD |
| 25 | | |
| 26 | 132A123 | DECAL (B thru F) |
| | 132A122 | DECAL (A Strut) |
| 27 | 132A120 | NON-SLIP (A thru C) |
| | 132A121 | NON-SLIP (D thru F) |
| 28 | 132A112 | DECAL (A STRUT) |
| | 132A113 | DECAL (B STRUT) |
| | 132A114 | DECAL (C STRUT) |
| | 132A115 | DECAL (D STRUT) |
| | 132A116 | DECAL (E STRUT) |
| | 132A117 | DECAL (E457 STRUT) |
| | 132A118 | DECAL (F711 STRUT) |
| | 132A119 | DECAL (F STRUT) |
| | | ' |

Form Part No. 172A291 Rev. 02