


# **Position Switch** 77640

Concealed/Flush Mount

Installation Instructions



7764 Magnetic Door

### Installation

- 1 Prepare frame for mortise installation of 7764 (see opposite side of sheet for wood frame).
- **3** Prepare door for magnet (see opposite side of sheet for wood door).

# A NOTE A


For maximum security, install the switch in the header, 2" from the lock stile edge.


Wire and install switch (see opposite side of sheet for wiring diagram).


4 Install magnet.


# $oldsymbol{A}$ note $oldsymbol{A}$

If switch does not work, check recommended gap and decrease if necessary.









## **Customer Service**

1-877-671-7011 www.allegion.com



© Allegion 2014 Printed in U.S.A. 77640 Rev. 01/14-e