- Topics
- My Posts
- More
- Categories
- Lunar Scout (LS)
  Guidelines
  - **ChatbotDocs**
- **≡** All categories
- Tags
- task-0
- task-1
- task-2
- other
- **●** task-4
- **≡** All tags

### ▲ Lunar Scout: Task 1A Mathematical Modeling -Theory (Part 2)

**Sep 2023** 

# Mathematical Modeling of a system

# Introduction to State Space Analysis

We had briefly covered State Variables and State Equations in previous Task. In this section we will further elaborate on that topic and discuss the various control techniques that are associated with that.

In control engineering, a **state-space representation** is a mathematical model of a
physical system as a set of input, output and state
variables related by first-order differential equations
or difference equations. **State variables** are
variables whose values evolve through time in a way
that depends on the values they have at any given
time and also depends on the externally imposed
values of input variables. Output variables' values
depend on the values of the state variables.

The state space equations for a linear time invariant system (LTI) system can be given as follows:

State Equation 
$$\Rightarrow \dot{x}(t) = Ax(t) + Bu(t)$$
  
Output Equation  $\Rightarrow y(t) = Cx(t) + Du(t)$ 

#### Here

- x(t)- State Vector (n x 1 matrix)
- y(t)- Output Vector (p x 1 matrix)
- u(t)- Input Vector (m x 1 matrix)
- A State (or system) matrix (n x n matrix)
- B Input matrix (n x m matrix)

T



C - Output Matrix (p x n matrix)

D - Feed-forward matrix (p x m matrix)

where p, m, n are:

We won't go into the theory of how these equations came into being. That's a lot of complicated math that cannot be covered here. You can refer to good Control Systems books.

Consider a set of equations:

$$\dot{x}_1 = x_1 x_2 - x_2 
\dot{x}_2 = 2x_1 - x_2^2$$
(1)

We want to express this set of equations into the form

$$\dot{x} = Ax \tag{2}$$

Notice, we have neglected the **Bu** term in this equation. That's because our system doesn't have any input. It only has state variables  $x_1$  and  $x_2$ .

Can we express the set of equations (1) in terms of (2)??

The answer is no, we cannot. (1) is a set of non linear equations while (2) is a set of linear equations. However, if we linearize (1), it might be possible to express (1) in terms of (2).

How do we linearize (1)? That was basically the whole point of previous Task.

#### 1. Find the equilibrium points

We want to find the point around which the system is stable. To find the equilibrium points we need to set  $\dot{x}_1 = 0$  and  $\dot{x}_2 = 0$ . Then solve the equations for

 $x_1$  and  $x_2$ .

$$0 = x_1 x_2 - x_2$$
$$0 = 2x_1 - x_2^2 \dots (3)$$

If we solve (3) for  $x_1$  and  $x_2$  we will get the equilibrium points as (0,0), (1, $\sqrt{2}$ ) and (1,- $\sqrt{2}$ ).

## 2. Calculate the jacobian of the system of equations

The jacobian J for the system of equations (3) will be:

$$J = \begin{bmatrix} \frac{\partial (x_1 x_2 - x_2)}{\partial x_1} & \frac{\partial (x_1 x_2 - x_2)}{\partial x_2} \\ \frac{\partial (2x_1 - x_2^2)}{\partial x_1} & \frac{\partial (2x_1 - x_2^2)}{\partial x_2} \end{bmatrix}$$
$$J = \begin{bmatrix} x_2 & x_1 - 1 \\ 2 & -2x_2 \end{bmatrix}$$

## 3. For each equilibrium point, calculate the value of the jacobian.

The values of jacobian for each equilibrium point will be given as:

$$\begin{split} J_{(0,0)} &= \begin{bmatrix} 0 & 0 - 1 \\ 2 & -2(0) \end{bmatrix} = \begin{bmatrix} 0 & -1 \\ 2 & 0 \end{bmatrix} \\ J_{(1,\sqrt{2})} &= \begin{bmatrix} \sqrt{2} & 1 - 1 \\ 2 & -2(\sqrt{2}) \end{bmatrix} = \begin{bmatrix} \sqrt{2} & 0 \\ 2 & -2\sqrt{2} \end{bmatrix} \\ J_{(1,-\sqrt{2})} &= \begin{bmatrix} -\sqrt{2} & 1 - 1 \\ 2 & -2(-\sqrt{2}) \end{bmatrix} = \begin{bmatrix} -\sqrt{2} & 0 \\ 2 & 2\sqrt{2} \end{bmatrix} \end{split}$$

# 4. Construct the state equation for each equilibrium point.

The state equation for equilibrium point (0,0) will be:

$$\begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \end{bmatrix} = \begin{bmatrix} 0 & -1 \\ 2 & 0 \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix}$$
Here,
$$\dot{x} = \begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \end{bmatrix}, \quad x = \begin{bmatrix} x_1 \\ x_2 \end{bmatrix}$$

$$A = \begin{bmatrix} 0 & -1 \\ 2 & 0 \end{bmatrix}$$

Therefore the set of equations has been expressed in the form:

$$\dot{x} = Ax$$

It is very important to note that this approximation of the set of non-linear equations given in (3) will only hold true for point close to the equilibrium point (0,0).

This means that around the vicinity of the equilibrium point (0,0), the non-linear system will behave like a linear system and the state equation given above will hold true around the vicinity of that point.

Likewise, the state equations for equilibrium points  $(1,\sqrt{2})$  and  $(1,-\sqrt{2})$  are:

$$\begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \end{bmatrix} = \begin{bmatrix} \sqrt{2} & 0 \\ 2 & -2\sqrt{2} \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix}$$
and
$$\begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \end{bmatrix} = \begin{bmatrix} -\sqrt{2} & 0 \\ 2 & 2\sqrt{2} \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix}$$

#### **Stability**

We can find out whether the system is stable or unstable at each of the equilibrium points by finding out the eigenvalues of the A matrix. If any of the eigenvalues have a positive real part, the system will be unstable.

So, for equilibrium point  $(1, \sqrt{2})$  of the system, the eigenvalues will be -2.824 and 1.414. Hence system will be unstable.

#### **Introducing Control Input**

Let us consider the Pendulum with external applied torque system.

We derived the equations for this system as:

$$\dot{x}_1 = x_2$$

$$\dot{x}_2 = \frac{-g}{l} \sin x_1 + \frac{1}{ml^2} T$$

We can apply the same linearization technique explained above.

#### 1. Find the equilibrium points.

If we set  $\dot{x}_I = 0$  and  $\dot{x}_2 = 0$ , we will find the equilibrium points of this system as  $(n\pi,0)$  where  $n=0,\pm 1,\pm 2,...$ . From the physical descriptions of the pendulum, it is clear that there are only two equilibrium positions (0,0) and  $(\pi,0)$ . The rest of equilibrium points are just repetitions based on number of full swings of the pendulum.

The equilibrium point (0,0) will be when the pendulum bob is vertically downwards.

The equilibrium point  $(\pi,0)$  will be when the pendulum bob is vertically upwards.

Intuitively, we can guess that the system will be stable at equilibrium point (0,0) and unstable at equilibrium point  $(\pi,0)$ . Let us see if our intuition is correct.

## 2. Calculate the jacobian of the system of equations.

The jacobian  $J_1$  for the A matrix of the state equation will be:

$$J_{1} = \begin{bmatrix} \frac{\partial(x_{2})}{\partial x_{1}} & \frac{\partial(x_{2})}{\partial x_{2}} \\ \frac{\partial(\frac{-g}{l}\sin x_{1} + \frac{1}{ml^{2}}T)}{\partial x_{1}} & \frac{\partial(\frac{-g}{l}\sin x_{1} + \frac{1}{ml^{2}}T)}{\partial x_{2}} \end{bmatrix}$$
$$J_{1} = \begin{bmatrix} 0 & 1 \\ \frac{-g}{l}\cos x_{1} & 0 \end{bmatrix}$$

Since our system has input, we also need to calculate jacobian  $J_2$  for the B matrix.

J<sub>2</sub> will be:

$$J_{2} = \begin{bmatrix} \frac{\partial f_{1}}{\partial u} \\ \frac{\partial f_{2}}{\partial u} \\ \frac{\partial f_{2}}{\partial u} \end{bmatrix}, \quad f_{1} = \dot{x}_{1}, f_{2} = \dot{x}_{2}$$
Since T is input, we replace T with u
$$J_{2} = \begin{bmatrix} \frac{\partial (x_{2})}{\partial u} \\ \frac{\partial (-g}{l} \sin x_{1} + \frac{1}{ml^{2}} u) \\ \frac{\partial u}{\partial u} \end{bmatrix}$$

$$J_{2} = \begin{bmatrix} 0 \\ \frac{1}{ml^{2}} \end{bmatrix}$$

# 3. For each equilibrium point, substitute value of $(x_1,x_2)$ in the jacobian and calculate the A and B matrix.

The values of A matrix for each equilibrium point will be given as:

$$A_{(0,0)} = \begin{bmatrix} 0 & 1 \\ -\frac{\mathcal{G}}{l} & 0 \end{bmatrix}, \qquad A_{(\pi,0)} = \begin{bmatrix} 0 & 1 \\ \frac{\mathcal{G}}{l} & 0 \end{bmatrix}$$

The values of B matrix for all equilibrium points will be:

$$B = \begin{bmatrix} 0 \\ \frac{1}{ml^2} \end{bmatrix}$$

## 4. Construct the state equation for each equilibrium point.

The state equation for equilibrium point (0,0) will be:

$$\begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \end{bmatrix} = \begin{bmatrix} 0 & 1 \\ -\frac{g}{l} & 0 \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix} + \begin{bmatrix} 0 \\ \frac{1}{ml^2} \end{bmatrix} u$$

The state equation for equilibrium point  $(\pi,0)$  will be:

$$\begin{bmatrix} \dot{x}_1 \\ \dot{x}_2 \end{bmatrix} = \begin{bmatrix} 0 & 1 \\ g & 0 \end{bmatrix} \begin{bmatrix} x_1 \\ x_2 \end{bmatrix} + \begin{bmatrix} 0 \\ \frac{1}{ml^2} \end{bmatrix} u$$

## 5. Check the stability of the system at each equilibrium point.

At equilibrium point (0,0) the eigenvalues will be:

$$\lambda = \pm \sqrt{\frac{g}{l}}i$$

At equilibrium point  $(\pi,0)$  the eigenvalues will be:

$$\lambda = \pm \sqrt{\frac{g}{l}}$$

The eigenvalues for (0,0) will be purely imaginary. Hence the system will be marginally stable. Marginally stable means that system will be continue to oscillate about the equilibrium point indefinitely.

The eigenvalues for  $(\pi,0)$  will be purely real. One of the eigenvalues will have positive real part. Hence the system will be unstable.

Hence we proved that our earlier intuitions about the stability of the system are correct. The system will be stable for (0,0) and unstable for  $(\pi,0)$ .

### **Controllability and Observability**

In control theory, controllability and observability are two very important properties of the system.

**Controllability** is the ability to drive a state from any initial value to a final value in finite amount of time by providing a suitable input. A matrix which determines if a system is fully controllable or not is called the controllability matrix.

Observability is the property of the system that for any possible sequnce of state and control inputs, the current state can be determined in finite time using only the outputs. A matrix which determines if a system is fully observable or not is called the observability matrix. A fully observable system means that it is possible to know all the state variables from the system outputs.

Controllability matrix (R) of a system is given by the following:

$$R = \begin{bmatrix} B & AB & A^2B & \dots & A^{n-1}B \end{bmatrix}$$

Observability matrix (O) of a system is given by the following:

$$O = \begin{bmatrix} C \\ CA \\ CA^2 \\ \vdots \\ CA^{n-1} \end{bmatrix}$$

If a system is fully controllable, then

$$rank(R) = n$$

If a system is fully observable, then

$$rank(O) = n$$

Here, n is the number of state variables.

Rank of a matrix is defines as the maximum number of linearly independent rows or columns in a matrix.

In the pendulum example (with external torque), we have the A and B matrix available to us. Hence we can calculate the controllability of the system.

$$R = \begin{bmatrix} 0 & \frac{1}{ml^2} \\ \frac{1}{ml^2} & 0 \end{bmatrix}$$

The rank of R is 2 which is equal to the number of state variables. Hence the system is fully controllable.

Take the following quiz before moving forward:

### Task 1A - Part 2 - Quiz

**ℰ** Lunar Scout: Task 1A - Theory Part 1 Quiz

Unlisted on Sep 17, 2023

Closed on Sep 19, 2023

### **Related Topics**

Topic	Replies	Views	Activity
TEAM ID:3280 Task1A practical task-1	14	276	Sep 2023
☑ Questionarie question 2	5	86	Dec 2023
<ul><li>✓ LS_2227 Failing to achieve Open loop oscillation task-1</li></ul>	3	250	Sep 2023
☑ Doubt in task3B question 2	1	65	Nov 2023
<b>≜</b> Lunar Scout: Task 1	3	9.6k	Sep 2023