AquaPure X2 — Installation and Maintenance Guide

Fictional content. Sample document for the RAG Generator demo.

Specifications

Dimensions: 42 cm (H) x 18 cm (W) x 38 cm (D). Weight: 9.5 kg. Tank capacity: 5 litres.

Filtration: 4 stages: sediment pre-filter, activated carbon filter (CF-200), reverse osmosis membrane (RM-75) and UV-C sterilisation lamp.

Operating water pressure: 1.0 to 6.0 bar. Water temperature: 4 to 38 degrees C. Power: 220-240 V, 48 W.

Installation

Install the unit on a level surface within 1.5 metres of a cold water supply. Do not install it in direct sunlight or where temperatures may fall below 4 degrees C.

Connect the supplied 1/4 inch inlet hose to the cold water tap adaptor. Open the tap slowly and check for leaks. Before first use, run the unit and discard the first 3 full tanks of water (15 litres).

Filter replacement schedule

Sediment pre-filter: replace every 6 months. Carbon filter (CF-200): replace every 12 months or after 3,000 litres, whichever comes first. RO membrane (RM-75): replace every 24 months.

The UV lamp is rated for 10,000 hours and should only be replaced by an authorised technician.

To replace the carbon filter: switch off the unit, open the front panel, twist the filter a quarter turn anticlockwise and pull it out. Insert the new filter and twist clockwise until it clicks. Hold the Reset button for 5 seconds to reset the filter counter.

Cleaning

Wipe the exterior with a damp cloth weekly. The water tank should be sanitised every 3 months using the self-clean cycle: hold the Clean button for 3 seconds. The cycle takes 10 minutes.