

Industrial Pump Maintenance SOP

Document ID: SOP-PUMP-001

Asset: Hydraulic Pump H1-2

Department: Mechanical Maintenance

Purpose

This SOP explains preventive maintenance for Hydraulic Pump H1-2 to reduce downtime and improve reliability.

Maintenance Schedule

- Inspect oil level every 7 days.
- Replace hydraulic oil every 6 months.
- Inspect seals every month.
- Bearing temperature should remain between 55°C and 70°C.
- Vibration should remain below 4.5 mm/s RMS.
- Replace inlet filter every 1000 operating hours.

Safety Precautions

- Lockout/Tagout before maintenance.
- Wear PPE.
- Depressurize hydraulic lines before opening.

Troubleshooting

High vibration may indicate bearing wear, shaft misalignment, loose mounting bolts, or cavitation.
Low pressure may indicate clogged filters.

Related Documents

Maintenance Log ML-2026-014

Incident Report IR-2026-008

Compliance Checklist CC-12