



Roof Floor FFL
12900



Lower Roof Floor FFL
9600



First Floor FFL
5100




Ground Floor FFL
600



Foundation Level
-1450



Roof
12800



Lower Roof
9500



First Floor
5000



Ground Floor
500



Foundation
-1450

