TEMCO LEARN

BACnet

1.0 · 2 pages · built Oct 30, 2026

1. BACnet at a glance
2. Points

BACnet at a glance

What a BACnet controller exposes, and how a supervisor finds it.

A Temco controller speaks BACnet so that a building supervisor can read it without knowing anything about Temco tools. This version documents the object model and the addresses; the wiring is Test1's business.

What a supervisor sees

Every point the controller holds is an object with an instance number. A supervisor reads a point by asking for its object identifier, which is the type and the number together — one 16-bit word, and the only addressing a BACnet device needs.

Finding it

A controller answers a **Who-Is** with an **I-Am**, which carries its device instance and its address. That is the whole discovery mechanism: no scan, no port number, no host name.

Where to go next

- Points — the object types this version exposes, and what each one is for

Points

The object types this version exposes, and the properties a supervisor reads from each.

A point is an object with a type and an instance. This version exposes the types below; anything not listed is not reachable over BACnet, however visible it is in the tool.

The types

Type	Name	What it holds
0	Analog input	A measured value: a temperature, a pressure, a 0–10 V signal
1	Analog output	A value the supervisor may write, such as a setpoint
3	Binary input	A switch or a proven state
4	Binary output	A relay the supervisor may command
19	Multi-state value	A mode: heating, cooling, off

The properties worth reading

- **Present value** — the point itself
- **Status flags** — whether the value is in alarm, overridden, or out of service
- **Reliability** — why a value might be wrong; read it before believing the value

A supervisor that reads present values and ignores status flags will report a fan as running while it is overridden off. Read the flags first.

Addressing

The instance number is printed beside the point in the tool and is what the supervisor asks for. Writing a point means asking for its object identifier and its priority array — and the lowest unused priority wins, which is how a supervisor overrides a program without deleting it.