BACnet

Points · built Oct 30, 2026

Points

The object types this version exposes, and the properties a supervisor reads from each.

A point is an object with a type and an instance. This version exposes the types below; anything not listed is not reachable over BACnet, however visible it is in the tool.

The types

Type	Name	What it holds
0	Analog input	A measured value: a temperature, a pressure, a 0–10 V signal
1	Analog output	A value the supervisor may write, such as a setpoint
3	Binary input	A switch or a proven state
4	Binary output	A relay the supervisor may command
19	Multi-state value	A mode: heating, cooling, off

The properties worth reading

- **Present value** — the point itself
- **Status flags** — whether the value is in alarm, overridden, or out of service
- **Reliability** — why a value might be wrong; read it before believing the value

A supervisor that reads present values and ignores status flags will report a fan as running while it is overridden off. Read the flags first.

Addressing

The instance number is printed beside the point in the tool and is what the supervisor asks for. Writing a point means asking for its object identifier and its priority array — and the lowest unused priority wins, which is how a supervisor overrides a program without deleting it.