PH Chart

Save and Load configuration · built Nov 12, 2026

Save and Load configuration

You can save all your work and load later if you wish. It saves all the configurations of nodes, charts, process lines, building information.


Once you load the file, you can get the saved configuration.

Note: The configuration will be saved in SQLite file format


For this feature, go to 'Save Configuration' and 'Load Configuration' under File Menue.

Save screenshots

Save the configuration




Save in your desired location as '.s3db' format




Load Screenshots

Load the configuration. Here you can see we have blank chart



Select the desired configuration file to load



Note: In the screenshot, we have shown for a single chart. It works same if you have many charts and many nodes.