Psychrometric Tool

Psychrometric Tool · built Nov 12, 2026

Psychrometric Tool

Reading air: dry-bulb and wet-bulb temperature, humidity, enthalpy, the chart itself, and the calculations that follow from it.

Contents

- Title
- Psychrometry and Psychrometric Chart
- Psychrometric Parameters
- The dry-bulb temperature (DBT)
- The wet-bulb temperature (WBT)
- Dew point temperature
- Relative humidity
- Moisture content
- Specific volume
- Enthalpy
- Example: Enthalpy Calculation
- Reading Parameters Using Chart
- Psychrometric Processes
- Sensible Heating of the Air
- Numerical Example: Sensible Heating
- Sensible Cooling of the Air
- Humidification
- Heating and Humidification Process
- Numerical Example: Heating and Humidification
- Cooling & Humidification
- Cooling & Dehumidification
- Numerical Example : Cooling & Dehumidification
- Heating and Dehumidification Process
- Adiabatic humidification (evaporative cooling)

- Adiabatic dehumidification (by absorbents)
- Mixing Process
- Numerical Example: Air Mixing
- Comfort Zone
- Numerical Example: Comfort Zone
- Miscellaneous Numerical Examples
- Application: HVAC
- Temco Psychrometric Tool
- T3000 & Psychrometric Tool
- Tool Componentns
- Reading Parameters
- Adding Charts and Nodes
- Node Repositioning
- Disconnect Process Line
- Node Grid View
- Edit Node Properties
- Edit Process Line Properties
- Working with comfort zones
- Clear chart and delete air handler
- Chart Printing
- Chart Saving
- Save and Load Configuration
- Weather Service
- Psychrometric Calculator
- Export Data
- Historical Data Plot
- References