TEMCO LEARN

Psychrometric Tool

Reading Parameters · built Nov 12, 2026

Reading Parameters

You can read all psychrometirc paraments of any pont inside the chart. You just need to hover the mouse inside the chart anad you can see all parameters in Psychro Parameters Panel. Please check the following screenshot:

