Psychrometric Tool

Save and Load Configuration · built Nov 12, 2026

Save and Load Configuration

You can save all your work and load later if you wish. It saves all the configurations of nodes, air handlers, process lines, comfort zones , building information.


Once you load the file, you can get the saved configuration.

Note: The configuration will be saved in SQLite file format


For this feature, go to 'Save Configuration' and 'Load Configuration' under File Menue.

Save screenshots

Save the configuration




Save in your desired location as '.s3db' format




Load Screenshots


Load the configuration. Here you can see we have blank chart



Select the desired configuration file to load



After selecting the saved configuration file, we got the following chart that we had saved before. Please note that chart was blank before loading.



Note: In the screenshot, we have shown for a single air handler. It works same if you have many air handlers and many nodes.