Bacnet Integration

Bacnet Integration

Software	Hardware	Bacnet		Modbus/Bacnet
Auto-Man	HOA	Out of	Output	Commands
AUTO	AUTO	FALSE	Follows local logic on the T3 controller, if any. Otherwise goes as commanded	Partial Control.
MAN- ON	AUTO	FALSE	Output is ON, managed by user at the PC or network commands	Writeable
MAN- OFF	AUTO	FALSE	Output is OFF, managed by user at the PC or network commands	Writeable
ANY	OFF	TRUE	Output is OFF, managed by user at the switch, network commands ignored	Ignored
ANY	ON	TRUE	Output is ON, managed by user at the switch , network commands ignored	Ignored