# T3000

List of Statements · built Nov 13, 2026

# List of Statements

The complete list of Control Basic statements and operators:

| STATEMENT | TYPE | DESCRIPTONSUMMARY |
|---|---|---|
| NUMBERS | DATA | Real numbers are handled by the T3000 in full floating point format |
| DAYS | DATA | Days are evaluated as an integer from SUN=0, MON=1, TUE = 2, WED=3... to SAT = 6 |
| DATES | DATA | Dates are handled internally by the T3000 as a number from JAN1=1 up to DEC31=365 |
| TIMES | DATA | Times are handled internally as hours, but can be typed HH:MM:SS in a program |
| VARIABLES | DATA | Variables are handled internally as real numbers with full floating point notation |
| NOT | OPERATOR | Evaluates to TRUE if the opposite is true. IF NOT HOT evaluates to true when COLD |
| ^ | OPERATOR | Exponent, raises a number to a power as in 2^2 = 4 |
| * / \ MOD | OPERATOR | Multiplication, division, integer portion of a division, remained of a division |
| + - | OPERATOR | Addition and subtraction |
| < > ... etc | OPERATOR | Less than, greater than, and other combinations. |

| | | |
|---|---|---|
| AND | LOGIC | Logical AND, both conditions must be TRUE for the expression to evaluate to TRUE |
| OR | LOGIC | Logical OR, if either expression is TRUE the result is TRUE |
| XOR | LOGIC | Logical Exclusive OR, evalutates to TRUE if the two expressions are different |
| ABS | FUNCTION | Absolute Value, returns the positive equivalent of a negative or positive number |
| ALARM | COMMAND | Causes an alarm, has built in hysterisis to avoid multiple alarms from the same event |
| ALARM-AT | COMMAND | Selects which panel will annunciate alarms, default is ALL panels |
| AVG | FUNCTION | Average of all numbers enclosed in the brackets following this command |
| CALL | COMMAND | Calls an other program which functions as a sub routine, takes arguments |
| CLEAR | COMMAND | Clears all the local variables in a given program |
| CLOSE | COMMAND | Sets a variable or out put to 0, same as STOP but is more intuitive in some cases |
| CONPROP | FUNCTION | Allows a Basic program to up date the proportional term in a particular PID controller |
| CONRATE | FUNCTION | Allows a Basic program to up date the derivative term in a particular PID controller |
| CONRESET | FUNCTION | Allows a Basic program to up date the integral term in a particular PID controller |
| DALARM | COMMAND | Delayed alarm, allows generation of alarms if a condition is true for a certain time |
| DECLARE | COMMAND | First line of a sub routine to accept the list of arguments from a CALL statement |
| DISABLE | COMMAND | Same as STOP or CLOSE, sets an item to 0 |
| DOM | FUNCTION | Day of month, returns the day of the month, starting with 1 on the first of the month |
| DOW | FUNCTION | Day of week, returns a number from 0 to 6 starting with Sun day as zero |
| DOY | FUNCTION | Day of the year, starting with Jan1 as 1 |
| ENABLE | COMMAND | Same as START or OPEN, sets the value of an item to 1. |

| | | |
|---|---|---|
| END | COMMAND | Ends execution of a program, T3000 assumes and end at the end of each program |
| FOR | COMMAND | Loop control statement, FOR A =1 TO 10 ....PRO GRAM LINES.....NEXT A |
| GOSUB | COMMAND | Branches to sub routine, executes program till next RE TURN statement, and loops back |
| GOTO | COMMAND | Unconditionally branches program execution to an other line |
| HANGUP | COMMAND | Ends a phone call in progress |
| IF | COMMAND | Logical decision, IF HEAT MODE THEN START OUT1 |
| IF+ | COMMAND | Executes the program line only once when the condition goes from FALSE to TRUE |
| IF- | COMMAND | Opposite of IF+, executes the line only when a condition be comes FALSE |
| INT | FUNCTION | Returns the integer part of an expression |
| INTERVAL | FUNCTION | IF IN TER VAL(0:01:00) executes the following programming once every minute |
| LET | COMMAND | Assignment operator, LET B = 20, has the same effect as B = 20 |
| LN | FUNCTION | Natural logarithm of the argument |
| LN-1 | FUNCTION | In verse logarithm of the argument |
| MAX | FUNCTION | Maximum of a list of arguments enclosed in brackets following the statement |
| MIN | FUNCTION | Minimum of a list of arguments enclosed in brackets following the statement |
| NEXT | COMMAND | Used in conjunction with the FOR statement to increment the loop counter |
| ON | COMMAND | ON VAR1 GOTO 100 , 200 , 300 , controls program path depending on VAR1 |
| ON-ALARM | COMMAND | Evaluates to TRUE when ever there is an alarm in the system. |
| ON-ERROR | COMMAND | Used with PHONE, REMOTE- GET, REMOTE- SET, and RUN- SYSTEM |
| OPEN | COMMAND | Sets an item to 1, OPEN OUT1 is the same as START OUT1 |
| PHONE | COMMAND | Phones a number, allows T3000 to dial with a modem for numeric paging |
| POWER - LOSS | FUNCTION | Looks for loss of power, 1 the first time the function is evaluated, o afterwards |

| | | |
|---|---|---|
| PRINT | COMMAND | Print strings at a printer connected to the panel |
| PRINT- AT | COMMAND | Print strings at a printer connected to an other panel on the net work |
| REM | COMMAND | Remark, used to add comments to a program |
| REMOTE-GET | COMMAND | 10 REMOTE- GET VAR1 = 2IN1, gets a reading from an other site via modem |
| REMOTE-SET | COMMAND | Sets a variable at a remote site via modem. |
| RE TURN | COMMAND | Causes program execution to return from a sub routine |
| RUN-MACRO | COMMAND | Causes a macro command or series of key strokes to be run |
| SCANS | FUNCTION | The number of scans a panel is per forming in one second |
| SET-PRINTER | COMMAND | Tells a T3000 system there is a printer at a particular panel |
| SQR | FUNCTION | Returns the square root of the argument |
| START | COMMAND | Sets the value of an items to 1, same as OUT1 = 1 or OPEN OUT1 |
| STATUS | FUNCTION | Status of a panel on the net work, 0 = No Comm, 1 =OK, 2 = no program |
| STOP | COMMAND | Sets the value of an items to 0, same as OUT1 = 0 or CLOSE OUT1 |
| TBL | FUNCTION | Looks up a value in a table |
| TIME | FUNCTION | Finds the current time |
| TIME-OFF | FUNCTION | Finds the time variable has been false |
| TIME-ON | FUNCTION | Finds the time variable has been true |
| WAIT | COMMAND | Pauses program execution |
| WR-ON | FUNCTION | Finds when a weekly routine is set to come on |
| WR-OFF | FUNCTION | Finds when a weekly routine is set to go off |
| UNACK | FUNCTION | Determines if there are unacknowledged alarms in system |
| USER-A | FUNCTION | Finds the user logged on to the local port |
| USER-B | FUNCTION | Finds the user logged on to the remote port |