ON- ERROR

Purpose:	To redirect program execution if there was an error.
Format:	ON-ERROR line
Description:	line is the line number
Example:	10 PHONE 555-1234
20 ON-ERROR 100	
30 REM CONTINUES HERE IF NO ERROR	
40 REM PROCEDURE IF CALL NOT SUCCESSFUL	
Note:	ON-ERROR can be used after the following statements:
PHONE REMOTE GET REMOTE	SET RUN-SYSTEM.