ON

Purpose: Selectable GOTO or GOSUB.

Format: ON n GOTO line [, line...]

ON n GOSUB line [, line...]

Description: n is an expression rounded to an integer line is a line number in the program

The value of n determines which line number in the list the program uses for branching. For ex am ple, if n is 3, the third line number in the list is the point to which the program branches.

If the value of n is illegal for the given list, no branch occurs.

Example:	10	VAR1 = AVG (IN1 , IN2 , IN3 , IN4) - 20
20	ON VAR1 GOSUB 100 , 200 , 300 , 400 , 500	
30 END		
100	REM THE AVERAGE IS 21 : RETURN	
200	REM THE AVERAGE IS 22 : RETURN	
300	REM THE AVERAGE IS 23 : RETURN	
400	REM THE AVERAGE IS 24 : RETURN	
500	REM THE AVERAGE IS 25 : RETURN	