T3000

RETURN · built Nov 13, 2026

RETURN

Purpose:	To return from a subroutine. Used in conjunction with GOSUB.	
Format:	RETURN	
Example:	10	GOSUB 150
20	REM CONTINUES HERE AFTER SUBROUTINE AT LINE 150	
30 END		
40	REM SPECIAL CALCULATIONS	
50	FACTOR = A * AVG(B , C , D) + 12	
60 RETURN		