CLOSE

CLOSE	
Purpose:	To set a value of a variable to 0 (i.e. off).
Format:	CLOSE variable
Example:	10 CLOSE VENT
20 CLOSE A	
30 CLOSE VAR1	