TEMCO LEARN

# BACnet

1.0 · 2 pages · built Oct 30, 2026

1. BACnet at a glance
2. Points

---

# BACnet at a glance

What a BACnet controller exposes, and how a supervisor finds it.

A Temco controller speaks BACnet so that a building supervisor can read it without knowing anything about Temco tools. This version documents the object model and the addresses; the wiring is Test1's business.

## What a supervisor sees

Every point the controller holds is an object with an instance number. A supervisor reads a point by asking for its object identifier, which is the type and the number together — one 16-bit word, and the only addressing a BACnet device needs.

## Finding it

A controller answers a **Who-Is** with an **I-Am**, which carries its device instance and its address. That is the whole discovery mechanism: no scan, no port number, no host name.

## Where to go next

- Points — the object types this version exposes, and what each one is for

# Points

The object types this version exposes, and the properties a supervisor reads from each.

A point is an object with a type and an instance. This version exposes the types below; anything not listed is not reachable over BACnet, however visible it is in the tool.

## The types

| Type | Name | What it holds |
|---|---|---|
| 0 | Analog input | A measured value: a temperature, a pressure, a 0–10 V signal |
| 1 | Analog output | A value the supervisor may write, such as a setpoint |
| 3 | Binary input | A switch or a proven state |
| 4 | Binary output | A relay the supervisor may command |
| 19 | Multi-state value | A mode: heating, cooling, off |

## The properties worth reading

- **Present value** — the point itself
- **Status flags** — whether the value is in alarm, overridden, or out of service
- **Reliability** — why a value might be wrong; read it before believing the value

A supervisor that reads present values and ignores status flags will report a fan as running while it is overridden off. Read the flags first.

## Addressing

The instance number is printed beside the point in the tool and is what the supervisor asks for. Writing a point means asking for its object identifier and its priority array — and the lowest unused priority wins, which is how a supervisor overrides a program without deleting it.