T3000

LET · built Nov 9, 2026

LET

LET	
Purpose:	Assigns the value of an expression to a variable.
Format:	LET a = x

Description: a is a variable

x is an expression

Example:	10	OUT1 = 5.5
20	LET VAR3 = ABS(6 * VAR1 - 100)	