T3000

START, STOP · built Nov 9, 2026

START, STOP

Purpose: To set a value of a variable to 1. Normally used to turn an output on. Also, normally only used with items which are configured as binary, ON-OFF for the range.

Format: START variable

Examples: 10 START OUT1

20 START A

30 START VAR1

STOP		
Purpose:	To set a value of a variable to 0(i.e. OFF).	
Format:	STOP variable	
Examples:	10	STOP OUT1
20 STOP A		
30 STOP VAR1		
40	STOP PRG10	