# WAIT

WAIT (T3000 only)

Purpose: To pause program execution.

| Format: | WAIT expression |
|---|---|
| Examples: | 10 START OUT2 |
| 20 WAIT 0:10 | |
| 30REM WAIT 10 MINUTES AT LINE 20 | |
| 40WAIT 00:00:10 | |
| 50REM WAIT 10 SECONDS AT LINE 30 | |
| 60WAIT 150 | |
| 70REM WAIT 1 HOUR AND 30 MINS AT LINE 40 | |
| 80WAIT A + B * AVG ( C , D ) | |
| 90REM WAIT WHATEVER THE EXPRESSION EVALUATES TO | |

Note:

This statement is handy for controlling timing sequences. Other programs in the panel will not be affected, only the program where the statement appears will be suspended.