Rock Mechanics.

Teemu Weckroth, September 7, 2023.

Rock mechanics.

Rock mechanics aims at studying the behaviour of rocks and rock masses under loads. While classical mechanics deals with mechanics of non-deformable particles, rock mechanics deals with the mechanics of deformable solid bodies.

Units.

Length
$$[L] = m$$

Area
$$[A] = m^2$$

Force
$$[\mathbf{F}] = N = kg \, m \, s^{-2}$$

Moment [
$$\mathbf{M}$$
] = N m = kg m² s⁻²

Strain
$$[\varepsilon] = -$$

Poisson's ratio
$$[\nu] = -$$

Pressure
$$[P] = N m^{-2} = Pa = kg m^{-1} s^{-2}$$

Stress
$$[\sigma] = N m^{-2} = Pa = kg m^{-1} s^{-2}$$

Young's modulus
$$[E] = N m^{-2} = Pa = kg m^{-1} s^{-2}$$

Concepts of stress and strain.

Strain in one dimension.

In one dimension, strain ε is defined as

$$\varepsilon = \frac{\Delta L}{L_0} = \frac{L_0 - L_1}{L_0}$$

with length displacement ΔL , initial length of sample L_0 , and final length of sample L_1 .

Stress in one dimension.

In one dimension, stress σ is defined as

$$\sigma = \frac{F}{A}$$

with force F and cross-sectional area of the sample A.

External loads.

Volume loads in $N m^{-3}$

Surface loads in N m⁻²

Line loads in N m⁻¹

Concentrated loads in N

These loads are characterised by their direction, sense, and magnitude.

Moment.

The moment of a force \mathbf{F} (or torque) about the point O is given by

$$\mathbf{M}_O = \mathbf{r} \times \mathbf{F}$$

and its magnitude is equal to

$$M_O = Fd$$

It quantifies the tendency of a force to rotate the body around a given point.

Global equilibrium of a body.

Consider a solid loaded by volume loads \mathbf{F} , surface loads \mathbf{T} , line loads \mathbf{Q} , and concentrated forces \mathbf{P}_i . The resulting force \mathbf{F}_0 must be equal to

$$\mathbf{F}_O = \int_V \mathbf{F} \, dV + \int_A \mathbf{T} \, dA + \int_L \mathbf{Q} \, dL + \sum_{i=1}^m \mathbf{P}_i = 0$$

The resulting moment \mathbf{M}_{O} must be equal to

$$\mathbf{M}_{O} = \int_{V} \mathbf{x} \times \mathbf{F} \, dV + \int_{A} \mathbf{x} \times \mathbf{T} \, dA + \int_{L} \mathbf{x} \times \mathbf{Q} \, dL + \sum_{i=1}^{m} \mathbf{x}_{i} \times \mathbf{P}_{i} = 0$$

These equations are the three equations of equilibrium in translation and the three equations of equilibrium in rotation.

Reactions.

Consider a body in equilibrium. It is common for such a solid to get support from the external world. These supports exert forces (or moments) on the body which ensures its equilibrium. They are called reactions. In general, the reactions are not known a priori.

Internal forces.

Any part of a body in equilibrium is in equilibrium.

Consider a body in equilibrium under a set of external loads and reactions. Imagine the body to be cut in two parts L and R. Each part should be in equilibrium, which is not possible with external loads and reactions only. Therefore new forces should appear on the plane π . These internal forces are due to the cohesion of matter.

The internal forces which exert on both parts of a (fictive) plane are in equilibrium: $\int \mathbf{T}_R \, \mathrm{d}A = \int \mathbf{T}_L \, \mathrm{d}A$. The internal forces on one side of the plane are in equilibrium with all external forces exerting from this side on the plane to the opposite side of the body.

Stress on a plane.

A force vector ${\bf F}$ on a (real or imaginary) plane can be decomposed into a normal force ${\bf F}_n$ acting normally to the plane and a shear force ${\bf F}_s$ acting tangentially to the plane.

$$\mathbf{F}_{n} = \mathbf{F}\cos\theta$$

$$\mathbf{F}_{s} = \mathbf{F} \sin \theta$$

There are normal stresses σ_n and shear stresses τ acting on the plane.

$$\sigma_{\rm n} = \lim_{\Delta A \to 0} \frac{\Delta \mathbf{F}_{\rm n}}{\Delta A}$$

$$\tau = \lim_{\Delta A \to 0} \frac{\Delta \mathbf{F}_{s}}{\Delta A}$$

stress vector
$$\mathbf{t}(\mathbf{x}) = \lim_{\Delta A \to 0} \left(\frac{\Delta \mathbf{F}}{\Delta A} \right) = \frac{d\mathbf{F}}{dA} = \begin{pmatrix} \sigma_n \\ \tau \end{pmatrix}$$

Consider a failure plane. The area of the failure plane is equal to

$$A' = \frac{A}{\cos \theta}$$

and the normal and shear stresses on the plane are equal to

$$\sigma_{n} = \frac{\mathbf{F}_{n}}{A'} = \frac{\mathbf{F}\cos\theta\cos\theta}{A} = \sigma_{y}\cos^{2}\theta$$
$$\tau = \frac{\mathbf{F}_{s}}{A'} = \frac{F\sin\theta\cos\theta}{A} = \sigma_{y}\sin\theta\cos\theta$$

Stress at a point (stress tensor).

The state of stress at any given point is defined by the force per unit area with reference to two perpendicular planes *x* and *y* through the point. In two dimensions, there are four stress components on a small square.

$$\begin{pmatrix} \sigma_x & \tau_{xy} \\ \tau_{yx} & \sigma_y \end{pmatrix}$$

In three dimensions, there are nine stress components on a small cube.

$$\begin{pmatrix} \sigma_x & \tau_{xy} & \tau_{xz} \\ \tau_{yx} & \sigma_y & \tau_{yz} \\ \tau_{zx} & \tau_{zy} & \sigma_z \end{pmatrix}$$

Sign convention: shear stresses are positive when they act in positive directions on negative faces.

Equilibrium: to ensure that the resulting moment is equal to zero, the corresponding shear stresses should be equal \rightarrow the stress tensor is symmetrical.

$$\begin{pmatrix} \sigma_{x} & \tau_{xy} \\ \tau_{xy} & \sigma_{y} \end{pmatrix}$$


$$\begin{pmatrix} \sigma_{x} & \tau_{xy} & \tau_{xz} \\ \tau_{xy} & \sigma_{y} & \tau_{yz} \\ \tau_{xz} & \tau_{yz} & \sigma_{z} \end{pmatrix}$$

The full stress transformation equations are expressed as

$$\sigma_{x'} = \sigma_x \cos^2 \theta + \sigma_y \sin^2 \theta + 2\tau_{xy} \sin \theta \cos \theta$$

$$\sigma_{y'} = \sigma_x \sin^2 \theta + \sigma_y \cos^2 \theta - 2\tau_{xy} \sin \theta \cos \theta$$

$$\tau_{x'y'} = \tau_{yy} (\cos^2 \theta - \sin^2 \theta) - (\sigma_x - \sigma_y) \sin \theta \cos \theta$$



The force vector represents the same force regardless of choice of coordinate system. The same holds for the stress tensor.

$$\mathbf{F} = F_{x} \cdot \mathbf{e}_{x} + F_{y} \cdot \mathbf{e}_{y}$$

$$= F_{x'} \cdot \mathbf{e}_{x'} + F_{y'} \cdot \mathbf{e}_{y'}$$

$$\begin{pmatrix} F_{x'} \\ F_{y'} \end{pmatrix} = \begin{pmatrix} \cos \theta & \sin \theta \\ -\sin \theta & \cos \theta \end{pmatrix} \begin{pmatrix} F_{x} \\ F_{y} \end{pmatrix}$$

Principal stresses.

There is an inclination θ^* of the axes at which all shear stresses disappear. The remaining stresses are principal stresses.

$$\begin{vmatrix} \sigma_1 & 0 \\ 0 & \sigma_3 \end{vmatrix}$$

In two dimensions $\sigma_3 \le \sigma_1$ with minor principal stress σ_3 and major principal stress σ_1 .

$$\sigma_{1} = \frac{1}{2}(\sigma_{x} + \sigma_{y}) + \sqrt{\tau_{xy}^{2} + \frac{1}{4}(\sigma_{x} - \sigma_{y})^{2}}$$

$$\sigma_{3} = \frac{1}{2}(\sigma_{x} + \sigma_{y}) - \sqrt{\tau_{xy}^{2} + \frac{1}{4}(\sigma_{x} - \sigma_{y})^{2}}$$

The orientation of the principal stresses are such that

$$\tan(2\theta^*) = \frac{2\tau_{xy}}{\sigma_x - \sigma_y}$$

Take
$$\delta = \operatorname{atan}\left(\frac{2\tau_{xy}}{\sigma_x - \sigma_y}\right)$$
 with $-\frac{\pi}{2} < \delta < \frac{\pi}{2}$.

$$\theta^* = \begin{cases} \frac{\delta}{2} & \text{if } \sigma_x > \sigma_y \\ \frac{\delta}{2} + \frac{\pi}{2} & \text{if } \sigma_x < \sigma_y \text{ and } \tau_{xy} > 0 \\ \frac{\delta}{2} - \frac{\pi}{2} & \text{if } \sigma_x < \sigma_y \text{ and } \tau_{xy} < 0 \end{cases}$$

Mohr circle.

If σ_1 and σ_3 are the principal stresses, then the state of stress on a plane inclined at an angle θ (measured anticlockwise from σ_1 to the normal of the plane) is given by

$$\begin{split} \sigma_{n} &= \sigma_{1} \cos^{2} \theta + \sigma_{3} \sin^{2} \theta \\ &= \frac{1}{2} (\sigma_{1} + \sigma_{3}) + \frac{1}{2} (\sigma_{1} - \sigma_{3}) \cos 2\theta \\ \tau &= (\sigma_{1} - \sigma_{3}) \sin \theta \cos \theta \\ &= \frac{1}{2} (\sigma_{1} - \sigma_{3}) \sin 2\theta \end{split}$$

The Mohr circle describes the normal and shear stresses acting on planes of all possible orientations through a stressed point in a solid.

Strain ε (strain tensor).

In one dimension, the strain at a point x is found by taking the limit of an infinitesimally short bar:

$$\varepsilon(x) = \lim_{L_0 \to 0} \frac{\Delta L}{L_0} = \lim_{\Delta x \to 0} \frac{u(x + \Delta x) - u(x)}{\Delta x} = \frac{\mathrm{d}u}{\mathrm{d}x}$$

Strain is essentially a measure of the relative displacement of nearby particles.

Normal strains lead to change in dimensions.

$$\varepsilon_{xx} = \frac{du_x}{dx}$$

$$\varepsilon_{yy} = \frac{du_y}{dy}$$

$$\varepsilon_{zz} = \frac{du_z}{dz}$$
Volumetric strain $\varepsilon_V = \frac{\Delta V}{V} = \varepsilon_{xx} + \varepsilon_{yy} + \varepsilon_{zz}$

Shear strains lead to change in angles.

$$\varepsilon_{xy} = \frac{1}{2} \left(\frac{du_x}{dy} + \frac{du_y}{dx} \right) = \varepsilon_{yx}$$

$$\varepsilon_{xz} = \frac{1}{2} \left(\frac{du_x}{dz} + \frac{du_z}{dx} \right) = \varepsilon_{zx}$$

$$\varepsilon_{yz} = \frac{1}{2} \left(\frac{du_y}{dz} + \frac{du_z}{dy} \right) = \varepsilon_{zy}$$

$$\gamma_{xy} = \frac{du_x}{dy} + \frac{du_y}{dx} = \alpha + \beta = \frac{1}{2} \varepsilon_{xy}$$

The components of the strain tensor can be listed out in matrix form.

$$\begin{pmatrix} \varepsilon_{x} & \varepsilon_{xy} & \varepsilon_{xz} \\ \varepsilon_{yx} & \varepsilon_{y} & \varepsilon_{yz} \\ \varepsilon_{zx} & \varepsilon_{zy} & \varepsilon_{z} \end{pmatrix}$$

Behaviour of rock material.

Young's modulus and Poisson's ratio.

These parameters characterise the behaviour of the material in the elastic region.

Young's modulus
$$E = \frac{\mathrm{d}\sigma_a}{\mathrm{d}\varepsilon_a}$$

Poisson's ratio $\nu = -\frac{\mathrm{d}\varepsilon_r}{\mathrm{d}\varepsilon_a}$

Unconfined (uniaxial) compression test.

Measured quantities:

- Axial compressive load F
- Change in measured axial length Δl
- Change in radius Δr

Transformed quantities:


- Axial stress $\sigma_a = \frac{F}{A_0}$
- Axial strain $\varepsilon_a = \frac{\Delta l}{l_0}$
- Radial strain $\varepsilon_r = \frac{\Delta r}{r_0}$

Stress-strain curve:

- Initial portion of the curve, concave upwards. Closing of initial micro-cracks.
- II. Linear elastic behaviour (both axially and radially).
- III. The axial stress-strain curve is nearly elastic. Significant acoustic emissions corresponding to an increase in micro-cracking can be recorded.
- IV. The rock has undergone a rapid acceleration of micro-cracking events and volume increases.
- V. Post-peak domain.

Peak strength = Uniaxial compressive strength = σ_c

= Maximum strength that a rock specimen can sustain under a given set of conditions



Rock material	E (GPa)	σ_c (MPa)
Chalk	0.1 to 12	0.1 to 12
Coal	1 to 6	2 to 100
Sandstone (soft)	1 to 10	1 to 10
Limestone (very soft)	3 to 10	2 to 10
Shale	10 to 70	10 to 70
Sandstone(hard)	20 to 80	20 to 80
Limestone (very hard)	50 to 100	100 to 300
Basalt	35 to 100	60 to 350

Rocks generally fail at a small strain, typically around 0.2% to 0.4%. Brittle rocks (typically crystalline rocks) have low strain at failure while soft rocks (e.g. shale and mudstone) tend to have relatively high strain at failure. Most rocks exhibit brittle behaviour under uniaxial compression.

Failure.

Strength in rock mechanics is defined as the peak stress a material can sustain (at failure.) However, the compression test does not have to end in rupture at that point but may proceed all the way to point *R*.

Confining stress.

At depth, rock is subjected to axial and lateral stresses. True triaxial compression means three different principal stresses. It is often simplified by making two lateral stresses equal to minor principal stress.

The behaviour of rock in triaxial compression changes with increasing confining pressure:

- · Peak strength increases.
- · Post-peak behaviour from brittle gradually changes to ductile.

Stress-strain behaviour at elastic region appears the same as uniaxial compression.

Brittle to ductile transition:

Rock type	Confining pressure MPa
Rock salt	0
Chalk	< 10
Shale	0 to 20
Limestone	20 to 100
Sandstone	> 100
Granite	>> 100

Failure criteria.

A failure criterion is a hypothesis concerning the stress at failure under any combination of stresses. It is an equation that links the stress components which will permit to predict the peak strengths developed under various stress combinations. It typically takes one of the following forms:

$$\sigma_1 = f(\sigma_2, \sigma_3)$$

$$\tau = f(\sigma_n)$$

Mohr-Coulomb criterion.


According to the Mohr-Coulomb criterion, the shear strength is made up of two parts:

$$\tau = c + \sigma_n \tan \phi$$
,

where c is a constant cohesion and $\sigma_n \tan \phi$ is a frictional component. It is a straight line with an intercept c on the τ -axis and an angle ϕ with the σ_n -axis.

The criterion assumes that a shear failure plane is developed in the rock material. When failure occurs, the stresses developed on the failure plane are on the failure criterion.

In the $\sigma_n\text{--}\tau$ diagram, when the Mohr circle touches the Mohr-Coulomb strength envelope, the stress condition on the failure plane meets the strength criterion.



Express σ_n and τ as functions of σ_1 and σ_3 :

$$\sigma_n = \frac{1}{2}(\sigma_1 + \sigma_3) + \frac{1}{2}(\sigma_1 - \sigma_3)\cos 2\theta$$
$$\tau = \frac{1}{2}(\sigma_1 - \sigma_3)\sin 2\theta$$

Rearranging

$$\frac{1}{2}(\sigma_1 - \sigma_3)\sin 2\theta = c + \left[\frac{1}{2}(\sigma_1 + \sigma_3) + \frac{1}{2}(\sigma_1 - \sigma_3)\cos 2\theta\right]\tan\phi$$

gives

$$\sigma_1 = \frac{2c + \sigma_3(\sin 2\theta + \tan \phi(1 - \cos 2\theta))}{\sin 2\theta - \tan \phi(1 + \cos 2\theta)}$$

The Mohr circle construction gives the orientation of the failure plane:

$$\theta = \frac{\pi}{4} + \frac{\phi}{2}$$

For the failure plane

$$\sin 2\theta = \cos \phi$$
 $\cos 2\theta = -\sin \phi$

so the Mohr-Coulomb criterion can be written as

$$\sigma_1 = \frac{2c\cos\phi + \sigma_3(1+\sin\phi)}{1-\sin\phi} = \frac{2c\cos\phi}{1-\sin\phi} + \sigma_3\frac{1+\sin\phi}{1-\sin\phi}$$
$$= \sigma_c + \sigma_3\tan\psi$$

According to the Mohr-Coulomb criterion, failure occurs when the applied shear stress minus the frictional resistance related to the normal stress on the failure plane

$$\tau - \sigma_{\rm n} \tan \phi = c$$

becomes equal to the rock cohesion.

The Mohr-Coulomb criterion has no physical meaning in presence of tensile normal stress. However, the Mohr-Coulomb criterion is often extrapolated into the tensile region until the tensile strength is reached.

Tensile cut-off.

Actual rock tensile strengths σ_t are lower than predicted by the Mohr-Coulomb criterion $\sigma_{t(MC)}$. A tensile cut-off is usually applied at a selected value of uniaxial tensile stress $\sigma_t = -T_0$ (at about $1/10\sigma_c$).

Hoek-Brown criterion.

The Mohr-Coulomb criterion is only suitable for the low range of confining stress. At high confining stress, it overestimates the strength. Therefore, a number of empirical strength criteria have been introduced for practical use. One of the most widely used criteria is the Hoek-Brown criterion of isotropic rock materials. The Hoek-Brown criterion is expressed as

$$\sigma_1 = \sigma_3 + (m\sigma_c\sigma_3 + \sigma_c^2)^{0.5}$$

with *m* a parameter that changes with rock type (usually between 5 and 30). The Hoek-Brown strength envelope is a curve. At high stress level, the envelope curves down. It gives a lower strength estimate that the Mohr-Coulomb criterion.

Effect of specimen size.

Both compressive strength and the brittleness are reduced for larger specimens. The elastic modulus does not vary significantly with specimen size. The larger the specimen, the greater the number of micro-cracks and hence the greater the likelihood of a more severe flaw.

Effect of specimen dimensions (constant V).

The elastic modulus does not vary significantly with specimen dimensions. Both the strength and the ductility increase as the aspect ratio (ratio of diameter to length) increases (effect of steel platens restraining deformation of the specimen).

Effect of water.

Deformation and failure of are controlled by the effective stresses

$$\sigma' = \sigma - p_w I$$

Deformability, compressive strength, and the post-peak behaviour of some rocks (especially those with a high clay mineral content) are affected by the moisture content.

- · Desiccation (the rock becomes more friable)
- · Swelling phenomena
- · Slaking phenomena (the rock can break down and crumble)

Effect of temperature.

Increase in temperature reduces the elastic modulus and compressive strength. Increase in temperature increases the ductility in the post-peak region.

Effect of pore fluid pressure.

Rocks are porous materials, and the pore space of a rock will in situ be filled with fluids under pressure. Deformation and failure of are controlled by the effective stresses

$$\sigma_1' = \sigma_1 - p$$
 $\sigma_2' = \sigma_2 - p$ $\sigma_3' = \sigma_3 - p$

where p is the pore fluid pressure.

Shear stresses are not affected by pore fluid pressure!

A pore fluid pressure p causes the same reduction in peak strength as a reduction of the external total pressure by an amount equal to p. The effect of pore fluid pressure can be input in the failure criteria simply by restating the conditions for failure in terms of effective stresses

Mohr-Coulomb criterion
$$\sigma_1' = \sigma_c + \sigma_3' \tan \psi$$

Hoek-Brown criterion $\sigma_1' = \sigma_2' + (m\sigma_c\sigma_2' + \sigma_c^2)^{0.5}$

In the context of a Mohr diagram, replacing the stresses σ_i with the effective stresses σ_i' has the effect of translating all the stress circles to the left by the amount p.

Underground excavations.

Types of underground excavations.

Underground excavation is a general term. It includes

- boreholes for water, hydrocarbon, or geothermal energy extraction (small diameter; vertical, horizontal, or inclined)
- · shafts for mine or tunnel access (large diameter; vertical)
- · tunnels for highways and railroads (large diameter; horizontal)
- caverns for hydroelectric power production and storage of water, oil, liquefied natural gas... (specific and non-circular geometries; large size; cyclic loading)
- caverns for mining purposes (intended to be stable while the ore is removed; or intentionally collapsed to produce broken rock that is drawn off as the ground caves)

The underground site is usually inaccessible until actual construction. The rock is initially stressed - the excavation causes changes in the stress state.


Problem description.

Consider a 2D cross-section. σ_{x0} and σ_{y0} are the (far-field) principal stresses. It is convenient to work with cylindrical system of coordinates. Define the normal stresses:

radial stress σ_r hoop stress σ_θ

Define the shear stress:

$$\tau_{r\theta} = \tau_{\theta r}$$



Kirsch analytical solution.

The Kirsch solution is the solution to the problem of a circular hole in a bi-axially loaded plate of homogeneous, isotropic, continuous, and linearly elastic material. It can be assimilated to a tunnel, well, or shaft which is sufficiently deep to neglect changes in state of stress around the zone of interest.

The elastic stress field around a circular opening is given by

$$\begin{split} \sigma_r &= \frac{\sigma_{x0} + \sigma_{y0}}{2} \left(1 - \frac{R^2}{r^2} \right) + \frac{\sigma_{x0} - \sigma_{y0}}{2} \left(1 - \frac{4R^2}{r^2} + \frac{3R^4}{r^4} \right) \cos 2\theta \\ \sigma_\theta &= \frac{\sigma_{x0} + \sigma_{y0}}{2} \left(1 + \frac{R^2}{r^2} \right) - \frac{\sigma_{x0} - \sigma_{y0}}{2} \left(1 + \frac{3R^4}{r^4} \right) \cos 2\theta \\ \tau_{r\theta} &= -\frac{\sigma_{x0} - \sigma_{y0}}{2} \left(1 + \frac{2R^2}{r^2} - \frac{3R^4}{r^4} \right) \sin 2\theta \end{split}$$

With the lateral earth pressure coefficient $K = \frac{\sigma_{x0}}{\sigma_{y0}}$

$$\sigma_r = \frac{\sigma_{y0}(K+1)}{2} \left(1 - \frac{R^2}{r^2} \right) + \frac{\sigma_{y0}(K-1)}{2} \left(1 - \frac{4R^2}{r^2} + \frac{3R^4}{r^4} \right) \cos 2\theta$$

$$\sigma_\theta = \frac{\sigma_{y0}(K+1)}{2} \left(1 + \frac{R^2}{r^2} \right) - \frac{\sigma_{y0}(K-1)}{2} \left(1 + \frac{3R^4}{r^4} \right) \cos 2\theta$$

$$\tau_{r\theta} = -\frac{\sigma_{y0}(K-1)}{2} \left(1 + \frac{2R^2}{r^2} - \frac{3R^4}{r^4} \right) \sin 2\theta$$

and


$$\frac{\sigma_r}{\sigma_{y0}} = \frac{K+1}{2} \left(1 - \frac{R^2}{r^2} \right) + \frac{K-1}{2} \left(1 - \frac{4R^2}{r^2} + \frac{3R^4}{r^4} \right) \cos 2\theta$$

$$\frac{\sigma_{\theta}}{\sigma_{y0}} = \frac{K+1}{2} \left(1 + \frac{R^2}{r^2} \right) - \frac{K-1}{2} \left(1 + \frac{3R^4}{r^4} \right) \cos 2\theta$$

$$\frac{\tau_{r\theta}}{\sigma_{y0}} = -\frac{K-1}{2} \left(1 + \frac{2R^2}{r^2} - \frac{3R^4}{r^4} \right) \sin 2\theta$$

Stress field for isotropic stress states (K = 1).

The stress field around a circular opening is given by



The opening alters the pre-existing states of stress.

Stresses at the boundary of a circular opening.

For r = R, the Kirsch equations yield


$$σ_r = 0$$
 (no internal pressure)
 $σ_θ = σ_{x0} + σ_{v0} - 2(σ_{x0} - σ_{v0})\cos 2θ$

or, if
$$\sigma_{x0} = K\sigma_{v0}$$

$$\sigma_{\theta} = \sigma_{y0} [(1+K) + 2(1-K)\cos 2\theta]$$

 $\tau_{r\theta} = 0$ (as the excavation boundary is a principal stress plane)

- (a) Under all stress fields, the opening alters the pre-existing state of stress (stress concentrations)
- (b) There is a linear variation with *K* of these stress concentrations
- (c) For an isotropic stress field (K = 1), the stress concentration is 2 everywhere on the boundary
- (d) In a uniaxial stress field (K = 0), the maximum stress concentration is 3 (compressive) and the minimum stress concentration is -1 (tensile)
- (e) Tension on the boundary can occur if $K < \frac{1}{3}$ (or > 3)



Stresses around a circular opening for K = 1.

For an isotropic stress field (K = 1), the Kirsch equations become

$$\begin{split} \sigma_r &= \sigma_{y0} \left(1 - \frac{R^2}{r^2}\right) + P \frac{R^2}{r^2} \\ \sigma_\theta &= \sigma_{y0} \left(1 + \frac{R^2}{r^2}\right) - P \frac{R^2}{r^2} \\ \tau_{r\theta} &= 0 \end{split}$$

with P an internal pressure.

- (a) When $P = \sigma_{y0}$, the internal pressure replaces the hydrostatic stress field present in the rock before excavation ($\sigma_r = \sigma_\theta = P$)
- (b) By pressurizing the fluid in a borehole, it is possible to produce conditions where $P > \sigma_{y0}$ and, if $P > 2\sigma_{y0}$, σ_{θ} will become negative (cf. hydraulic fracturing)

Induced displacement.

The magnitude of the displacements depends both on the natural stress field $(\sigma_{x0}, \sigma_{y0})$ and rock mass deformability (G, v). Radial displacement

$$u_r = \frac{\sigma_{x0} + \sigma_{y0}}{4G} \frac{R^2}{r} + \frac{\sigma_{x0} - \sigma_{y0}}{4G} \frac{R^2}{r} \left[4(1 - v) - \frac{R^2}{r^2} \right] \cos 2\theta$$

Orthoradial displacement

$$u_{\theta} = -\frac{\sigma_{x0} - \sigma_{y0}}{4G} \frac{R^2}{r} \left[2(1 - v) + \frac{R^2}{r^2} \right] \sin 2\theta$$

Stress-controlled instabilities.

The Kirsch equations do not hold once the rock mass strength is reached (failure criterion) → stress-controlled instabilities.

In **weak and soft** rock, the yielding may result in large convergence displacements (squeezing) where these displacements are a function of the size of the plastic zone relative to the tunnel diameter. In **hard and strong** rock, the yielding may result in relatively small convergence displacements as long as the depth of the brittle failure is limited and the bulking process in the failing rock is well controlled.

The Kirsch solution can provide considerable insight into support design as it can be used to perform different types of preliminary investigations, such as the determination of the zone influenced by an excavation and the identification of high stress regions where potential inelastic deformation may occur around excavations.


Another type of stress-induced instability includes the possibility of **slip on pre-existing discontinuities** of the induced stress field. Slip on a pre-existing discontinuity will happen if the induced stresses locally satisfy the discontinuity shear strength criterion.

Procedure:

- Evaluate the stress components on the discontinuity using the Kirsch equations
- 2. Transform these components into normal and shear stress components acting on the discontinuity
- 3. Compare them to the discontinuity shear strength criterion

In situ stress.

Rocks differ from other materials in other fields because they are initially under stress. The state of stress in the subsurface prior to excavation is called the *in situ* stress state. The in situ stress state influences the stability of underground and surface excavations.



Determining the stress state.

The state of stress at any point is defined with the stress tenor. Determining the stress state means determining the component of the stress tenor and determining the principal stress orientation. Any system utilised for estimating the in situ stress state must involve a minimum of **six** independent measurements. Direct stress measurement vs indirect methods/indicators.

In situ stress origins.

Lithostatic stress from weight of overlying geological materials.
 Horizontal stress


$$\sigma_h = \sigma_H = K\sigma_v = \frac{v}{1 - v}\sigma_v$$

with $\nu \approx 0.15$ to 0.35, $K \approx 0.18$ to 0.54, and $\nu = -\varepsilon_r/\varepsilon_a$. Vertical stress

$$\sigma_v = \rho gz$$

with $\rho g \approx 0.027 \,\mathrm{MPa}\,\mathrm{m}^{-1}$.

2. **Tectonic stress** is responsible for the movement of lithospheric plates. Stress state is in between active (normal faulting) and passive (reverse faulting) failure using Mohr Coulomb.



The mean worldwide horizontal stress does not follow the trend predicted by the elastic theory except at depths of several km. For 0 < z < 500 m, $\sigma_{H,avg} > \sigma_v$ for 90% of cases.

In situ stress influences.


- 1. Surface topography.
 - Concave downward → large stress
 - Concave upward → low stress
 - Free surface with no stress acting on it → principal stress plane with zero normal stress
 - · V-notch valley → very high horizontal *in situ* stresses

The vertical direction is not always the principal stress direction.

2. **Erosion.** When part of the overburden is eliminated from an area, the value of the vertical stress σ_{v} is lowered and the state of stress and relationships between the acting stresses are modified.

$$K(z) = K_0 + \left[\left(K_0 - \frac{\nu}{1 - \nu} \right) \Delta z \right] \frac{1}{z}$$

- 3. Fault and faulting.
- Intrusion. Discontinuities: effect of stiffness of discontinuity filling material on stress state.



Hydraulic fracturing.

The objective of hydraulic fracturing is to measure at great depth (> 50m and up to 5 km) and through a borehole the magnitude and direction of the maximum and minimum principal stresses on a plane perpendicular to the borehole.

The procedure consists of the following steps:

- 1. A length of borehole is chosen for the stress measurement, and an interval (typically 1 m) is located for the test
- 2. The interval is isolated using a packer system
- 3. The isolated zone is pressurized by water until a fracture occurs in the rock
- 4. Three measurements are taken:
 - Breakdown pressure P_f: water pressure when the fracture occurs
 - **Shut-in pressure** P_s : subsequent pressure required to hold the fracture open
 - Fracture re-opening pressure P_r : pressure required to re-open the fracture

Assumes that a vertical borehole is drilled in a non-porous, impermeable formation and the three principal stresses are the vertical stress σ_{v} and the horizontal stresses σ_{H} and σ_{h} with $\sigma_{H} > \sigma_{h}$. Kirsch analytical solution in slides. Initially $\sigma_{\theta}(A) = 3\theta_{h} - \sigma_{H}$.

 The fluid is pumped to the borehole section insulated by the two packers → the fluid pressure in the borehole increases:

$$\sigma_{\rm A}(A) = 3\sigma_{\rm h} - \sigma_{\rm H} - P$$

 More fluid is injected in the borehole section insulated by the two packers → the borehole pressure reaches the rock fracturing pressure → the fracture initiates:

$$\sigma_{\theta}(A) = 3\sigma_h - \sigma_H - P_f = -T_0$$

- \rightarrow the fracture propagates in the direction perpendicular to the minimum *in situ* stress (assumption) but the fluid pressure in the fracture drops.
- 3. When the fluid pressure equals σ_h , the fracture cannot propagate further and closes. The shut-in pressure is such that

$$P = P_s = \sigma_h$$

4. The fluid pressure is increased again to re-open the fracture:

$$\sigma_{\theta}(A) = 3\sigma_h - \sigma_H - P_r = 0$$

Derived from the equations above:

$$\sigma_h = P_s$$


$$(P_f - P_r) = T_0$$

$$\sigma_H = 3\sigma_h - P_r$$

Flat jack.

- 1. Two pins are drilled and fixed into an excavation boundary. The distance between them is denoted $d_{\rm 0}$.
- 2. A slot is cut into the rock halfway between the pins.
- 3. As the rock is cut, the pins will move together (if the normal stress is compressive).
- 4. A flat jack is grouted in the slot.
- 5. The flat jack is pressurised with oil or water.
- 6. The pins move apart.

The flat jack is said to be a self-compensating method of stress determination. **One** normal stress component across the flat-jack can be determined using the flat jack method. **Six** tests with different independent orientations and locations are needed to fully characterise the *in situ* state of stress.



In practice: performed at a rock face; pressures until 34.5 MPa (if careful welding); d_0 is typically six inches (15.2 cm).

Discontinuities characterisation and behaviour.

Impact of discontinuities on rock masses.

Tunnels. Influences of the pre-existing discontinuities on the nucleation of new creaks — weakness zone. Effect: blocks might fall from the roof of a tunnel due to intersecting joint planes; at a larger scale, whole chambers can collapse owing to unfortunate intersections of planar weaknesses. **Slopes**. Influence of the pre-existing discontinuities and of the slope on unstable block of rocks (toppling). Effects: column of rocks rotates at the base of the slope and falls; toppling failure occurs in nature but also in mining excavation where the confining stresses are reduced.

Basic characteristics of discontinuities.

A discontinuity is a planar structure in the rock. Structural discontinuities occur at different scales and in different contexts.

Geometric attributes of discontinuity systems:

- · Discontinuity orientation and sets
- · Persistence
- · Spacing and block sizes
- · Roughness and aperture

Discontinuity orientations and sets.

Characterisation. Orientation of discontinuities controls the possibility of unstable conditions or excessive deformations. The orientation of discontinuities determine the shape of rock blocks. The orientation is defined by the direction of the plane (strike) and its dip.

Notation. Discontinuities are organised in networks composed of one or more sets. Sets are generally defined based on their orientations. The most common networks are orthogonal, conjugated, hexagonal, and polygonal — best way to observe them is in outcrops.

Characterising sets. Mechanical properties of the rock mass are influenced by discontinuities sets. More sets = more possibilities for potential slide planes. One set cuts the rock into planes, two orthogonal sets into columns, and three into blocks.

ISRM suggested classification:

I	Massive, occasional random fractures
II	One joint set
III	One joint set plus random fractures
IV	Two joint sets
V	Two joint sets plus random fractures
VI	Three joint sets
VII	Three joint sets plus random fracture
VIII	Four or more joint sets
IX	Crushed rock_earth-like

Persistence, spacing, and block size.

Persistence. The persistence is the areal extent of a rock discontinuity. The persistence of sets of discontinuities controls large-scale rock or structural failure.

ISRM Suggested Description	Surface Trace Length (m)
Very low persistence	< 1
Low persistence	1 to 3
Medium persistence	3 to 10
High persistence	10 to 20
Very high persistence	> 20

Spacing. The fracturing degree of a rock mass is controlled by the number of discontinuities in the rock mass. More discontinuities implies a decrease of the spacing. Discontinuity spacing controls the size of individual rock blocks (failing mode). Discontinuity spacing is the orthogonal distance between two consecutive discontinuities.

Frequency/density of discontinuities. Discontinuity frequency λ is the number of discontinuity per unit length (i.e. inverse of joint spacing s_i):

$$\lambda = \frac{1}{s_i}$$

The frequency is linked with the density of fracturing.

Description	Joint Spacing (m)
Extremely close spacing	< 0.02
Very close spacing	0.02 to 0.06
Close spacing	0.06 to 0.2
Moderate spacing	0.2 to 0.6
Wide spacing	0.6 to 2
Very wide spacing	2 to 6
Extremely wide spacing	> 6

Rock quality designation. Expresses the percentage of segments of intact rocks of more than $10 \text{ cm} \log (L_1)$ over the considered length (L):

$$RQD = \frac{\sum L_i}{L} \cdot 100\%, \quad L_i > 10 \,\mathrm{cm}$$

Very poor	0 % to 25 %
Poor	25 % to 50 %
Fair	50 % to 75 %
Good	75 % to 90 %
Excellence	90 % to 100 %

Roughness.

Defines the morphology of discontinuity walls. Varies from smooth to very rough. Walls can be in contact and matched or poorly linked and mismatched. The roughness controls the resistance to present-day shear stress: very rough surfaces in good contact will be much more difficult to displace than smooth ones.

Discontinuity surface roughness is a measure of surface unevenness and waviness relative to its mean plane. The roughness is characterised by large-scale waviness (undulation) and small-scale unevenness (irregularity) of a discontinuity surface. The roughness principal governing factor of the direction of hear displacement and shear strength, in turn, the stability of potentially sliding blocks.

Should first be described qualitatively at metre scale (step, undulating, planar) and then at centimetre scale (rough, smooth, slickensided). Joint Roughness Coefficient (JRC) is a quantitative measure of roughness, varying from 0 for the smooth flat surface to 20 for the very rough surface.

Aperture.

In a natural joint, it is very seldom that the two surfaces are in complete contact. The perpendicular distance separating the adjacent rock walls is termed as aperture. Joint opening is either filled with air and water (open joint) or with infill materials (filled joint). Joints with large apertures have low shear strength. Aperture associates with flow and permeability.

Aperture	Description	
< 0.1 mm	Very tight	
0.1 mm to 0.25 mm	Tight	Closed fracture
0.25 mm to 0.5 mm	Partly open	
0.5 mm to 2.5 mm	Open	Gapped
2.5 mm to 10 mm	Widely open	feature
1 cm to 10 cm	Very widely open	
10 cm to 100 cm	Extremely widely open	Open feature
> 1 m	Cavernous	

Can be expressed as a function of length but also as a function of reactivation from present day *in situ* stress. Aperture can be the real aperture or the equivalent hydraulic aperture.

Filling is material in the rock discontinuities separating the adjacent rock surfaces. Filled discontinuity is the only way of evaluating real aperture occurring in subsurface condition. In general, properties of the filling material affect shear strength, deformability, and permeability of the discontinuities.

Key mechanical properties.


Previously we discussed the mechanical behaviour of intact rock via the stress-strain curve. Here, consider the equivalent behaviour of a discontinuity loaded in compression and/or shear.

Normal stress
$$\sigma_n = \frac{N}{A}$$

Normal displacement Δn


Shear stress
$$\tau = \frac{T}{A}$$

Shear displacement Δs



Shear strength of rock joints.

Conditions for sliding of rock blocks along existing joints and faults at slope or excavation opening are governed by the shear stress developed on the sliding rock discontinuities and shear strength. For a test carried out at a constant normal stress, a typical plot of the shear stress against the shear displacement is



At small displacements, the specimen behaves elastically and the shear stress increases linearly with displacement. As the force resisting movement is overcome, the curve becomes non-linear and then reaches a maximum that represents the peak shear strength of the discontinuity. Thereafter, the stress required to cause displacement decreases and eventually reaches a constant value termed the residual shear strength.

Friction angle of rock surfaces.

For a planar, clean (no infilling) discontinuity, the cohesion will be zero and the shear strength will be defined solely by the friction angle. The basic friction angle of the rock material is related to the size and shape of the grains exposed on the fracture surface

- Fine-grained rock and rock with a high mica content will tend to have a low friction angle
- · Coarse-grained rock will have a high friction angle

Rock class	Friction angle	Typical rock types
Low friction	20° to 27°	Schists (high mica content), shale, marl
Medium friction	27° to 34°	Sandstone, siltstone, chalk, gneiss, slate
High friction	34° to 40°	Basalt, granite, limestone, conglomerate

Shearing on an inclined plane.

If the discontinuity surface is inclined at an angle i to the shear stress direction, the shear and normal stresses acting on the sliding surface are given by


$$\tau_i = \tau \cos^2 i - \sigma \sin i \cos i$$

$$\sigma_i = \sigma \cos^2 i + \tau \sin i \cos i$$

If it is assumed that the discontinuity surface has zero cohesion and that its shear strength is $\tau_i = \sigma_i \tan \phi$, then

$$\tau = \sigma \tan(\phi + i)$$

where ϕ is the basic friction angle and $(\phi + i)$ is the apparent friction angle.




Effect of surface roughness.

The same equation is valid for a rough discontinuity with an average asperity inclination i:

$$\tau = \sigma \tan(\phi + 1)$$

The dilation (normal displacement Δn) due to the shear displacement Δs is given by


$$\Delta n = \Delta s \tan i$$



For higher levels of normal stress, the shear displacement will shear off asperities, with consequent reduction of the effective friction angle and of the normal dilation. In the limit, as normal stress approaches the joint compressive strength, the effective friction angle tends to the basic friction angle.

Shear strength model I: Mohr-Coulomb.

We obtain a residual failure envelope with the residual shear strength. Cohesion disappears in the residual state. Stress states in the blue zone are not possible in the residual strength condition.



with peak friction angle ϕ_p , residual friction angle ϕ_r , and cohesion of the cementing material c.

Shear strength model II: bi-linear model.

Shear strength for a rough fracture could exhibit two features: at low normal stress shearing by climbing the asperity angle; at high stress shearing off the asperities. This leads to a bilinear shear strength model

$$\tau = \sigma_n \tan(\phi + 1) \qquad \text{for } \sigma_n \le \sigma_n^*$$

$$\tau = c + \sigma_n \tan(\phi) \qquad \text{for } \sigma_n \ge \sigma_n^*$$

where σ_n^* is the critical normal stress when shearing of asperity is assumed to start.

Shear strength model III: JRC-JCS empirical model.

In reality, there is no clear boundary between shearing by climbing asperity and shearing off asperities. The actual shear stress-normal stress relation is represented by a curve, and could be represented by the empirical relation

$$\tau = \sigma_n \tan \left[\text{JRC} \log_{10} \left(\frac{\text{JCS}}{\sigma_n} \right) + \phi_r \right]$$

with effective normal stress σ_n , joint roughness coefficient JRC, joint wall compressive strength JCS, and drained residual friction angle ϕ_r . Comments: it has the basic form of friction law; high JRC gives high dilation angle (i); higher JCS delays the reduction of i, since strong rock has less shearing off; it is widely accepted and used in rock engineering.

Peak shear strength modes.

Joint surface profile is a 3D feature, while shearing is a directional activity. Surface profile along a particular direction would be different along another direction and hence gives different shear strength.


Water and rock joint shear strength.

When a joint is wet, it has generally a lower friction angle than a dry joint. When shear strength of a wet joint is calculated, use the wet (and drained) friction angle. If a joint is submerged to water pressure, normal stress is the shear strength equation is the effective normal stress.

$$\tau = c + (\sigma_n - p_{w_i}) \tan(\phi + i)$$

Stereographic projections.

- 1. A line or a plane is measured into an outcrop.
- 2. Include the discontinuity at the centre of a sphere. The line or the plane is, by convention, localised in the lower hemisphere.
- 3. For a line, the point of intersection with the sphere envelope is called the spherical projection of the line. For a plane, the intersection with the sphere envelope is the great circle.
- 4. If we had the sphere in front of us, the structural line is a point in the lower hemisphere and a plane is a great circle.
- 5. Project lines and plane on the equatorial plane or plane of projection. Any point on the lower hemisphere projects a dot on the plane of projection and a great circle becomes a circular arc.



Surface excavations.

Needed when linear infrastructure or mining requires the construction of either a level surface on natural slopes or a pre-determined depth below ground level. Slope stability is determined by

- · Geometric factors (height, angle, orientation)
- · Geological factors (discontinuities, anisotropy)
- · Hydrogeological factors (water, permeability)
- · Geomechanical factors (strength, deformability and permeability)


Modes of failure.

Different types of rock slope failure are conditioned by

- The characteristics of the rock mass (number of joint sets, orientation of the discontinuities, characteristics of the discontinuities...)
- The orientation of the slope face with respect to the orientation and distribution of the discontinuities

The stability is defined by the strength of the discontinuities and the intact rock

- In hard or strong rock masses, the location of the failure planes is determined by the discontinuities
- In weak rock masses, intact rock also plays an important part in the development and location of such planes and in the failure mechanism



(a) Circular failure.

Usually occurs in waste rock, heavily fractured rock, and weak rock with no identifiable structural pattern. The failure surface is free to find a line of least resistance through the slope. The crushed or highly fractured rock masses are assumed to be homogeneous, and the shear strengths are controlled by cohesion and friction. Circular failure analysis: analytical methods as in soil mechanics; c and ϕ are for rock mass.

(b) Plane failure.

Occurs in rocks with plane discontinuities, e.g. bedding planes. Necessary criteria for kinematic feasibility:

- 1. The potential sliding plane dips out of the slope
- 2. The dip of the slope must exceed that of the potential slide plane
- 3. The dip of the potential slide plane is such that the strength of the plane is reached

(c) Wedge failure.

Occurs when two planes of weakness intersect to define a tetrahedral block. Necessary criteria for the kinematic feasibility:

- 1. The potential intersection line must dip out of the slope
- 2. The dip of the slope must exceed that of the potential slide line
- 3. The dip of the potential slide line is such that the strength of the line is reached

(d) Toppling failure.

Occurs in rocks with columnar or block structures separated by steeply dipping discontinuities. Two types of toppling failure

- Direct toppling: if there are frequent cross joints, the layers can overturn as rigid columns
- Flexural toppling: each layer tending to bend down-hill under its own weight transfers force downslope. If the toe of the slope is allowed to slide, flexural cracks will form in the layers above, liberating a large mass of rock

Stability analysis.

The analysis of rock slope stability is fundamentally dependent on a detailed analysis of the rock mass structure. A kinematic analysis is then performed to determine the influence of the discontinuities on stability and identify possible modes of slope failure. Involves studying the relationship between the orientation of the discontinuity and the face.


Limit equilibrium analysis.

Calculates the factor of safety of the slope. The forces tending towards movement along a given failure surface are compared with the forces resisting it. The Factor of Safety (FoS) is defined as

$$FoS = \frac{Forces \ resisting \ slide}{Forces \ tending \ to \ slide} = \frac{\sum R}{\sum S} = \frac{Resisting \ shear \ stress}{Sliding \ shear \ stress}$$

The slope is stable if FoS > 1.

- 1. Section of potential sliding surface(s)
- 2. Triggering and resisting forces
- 3. Mohr-Coulomb failure criterion
- 4. Definition of factor of safety (FoS)



FoS =
$$\frac{\tau_{\text{res}}}{\tau_{\text{sl}}} = \frac{c + \frac{W \cos \alpha}{A} \tan \phi}{\frac{W \sin \alpha}{A}} = \frac{cA + W \cos \alpha \tan \phi}{W \sin \alpha}$$
$$= \frac{R_c + R_\phi}{W \sin \alpha}$$

$$\sigma_n = \frac{W \cos \alpha}{A}$$
 $\tau_{sl} = \frac{W \sin \alpha}{A}$ $\tau = c + \sigma_n \tan \phi$

Limit-equilibrium analysis is based on

- · Section of potential sliding surface(s)
- · Mohr-Coulomb failure criterion
- · Definition of FoS
 - 1. Identification of all forces acting on the sliding mass
 - 2. Calculation of the resultant resisting and driving forces
 - 3. Calculation of the FoS

Slope stabilisation measures.

Five general categories of slope stabilisation measures:

- 1. Change of the slope geometry
 - Modifying the slope geometry redistributes forces due to the weight of the materials to obtain a more stable configuration
 - It may include reducing the slope angle, removing weight at the head of the slope, increasing weight at the slope toe, constructing benches and berms (stepping)
 - Rock removal should only be used where it is certain that the new face will be stable, and there is no risk of undermining the upper part of the slope
- 2. Mechanical stabilisation
 - Mechanical methods of slope stabilisation are those that alter or protect the slope face to reduce erosion, prevent rock fall, or to reduce ravelling
 - Common methods include protective blankets, geotextiles, and wire nets/meshes
- 3. Structural stabilisation
 - Structural stabilisation includes those methods that reinforce the structure of the rock at the slope face or provide a structure that supports the slope
 - Methods available include the use of gunite or shotcrete, the use of rock bolting, the construction of rock buttresses, and the construction of retaining walls

Pre-tensioned rock bolt

$$FoS = \frac{[W\cos\alpha + T\sin(\alpha + \beta)] \cdot \tan\phi}{W\sin\alpha - T\cos(\alpha + \beta)}$$

Pre-tensioned net

$$FoS = \frac{[W\cos\alpha + p \cdot A] \cdot \phi}{W\sin\alpha}$$

- 4. Vegetative stabilisation
 - Most frequently used for aesthetic purposes, such as slope reclamation
 - Generally, these methods are most successful when minor or shallow instability (such as ravelling or erosion) is involved, as is usually the case for soil slopes or highly fractured rock slopes
- 5. Water control
 - Groundwater in rock slopes is often a primary or contributory cause of instability: reduction of the shear strength of the potential failure surface; accelerate weathering; expansion of openings when freezing; erosion
 - · A reduction in water pressures usually improves stability
 - Drainage can be at ground level (drainage ditches, channels...)
 or at depth (horizontal drains, wells, drainage walls...)