

Application Note: Resetting a Target Board

INTRODUCTION

In some cases, updating the software on a FreeETarget will cause the board to appear disabled or broken. This is because when going from an old to new version, the board needs to be reinitialized. This is a simple three step process.


RESETTING THE BOARD

- 1 – Connect to the target using the PC Client
 - 2 - Start the Debug Terminal using the ESP32 Icon.



- ### 3 – End the Self Test


You will observe the target repetitively sending a list of numbers as shown below.



Enter an ! (exclamation mark) in the Generic Command box and press SEND

4 – Provide a serial number

The test will end and you will be prompted to enter a serial number



In the Generic Command box enter the serial number printed on the circuit board.

Add an exclamation mark to the end of the serial number and press SEND. (Example 1234!)

5 – The test will end and the target go into service

