

Print at 100% on 200–300 gsm cardstock. Score all fold lines before folding.

A — PREPARE BULKHEADS (B1/B2)

1) CUT B1 and B2 on black solid lines. 2) SCORE BLUE lines and fold side glue tabs to 90°. 3) CUT the alternating windows exactly as printed. 4) Keep windows mirrored: B1 top-left, B2 top-right.

B — WHY BAFFLES (ANTI-JAM)

Baffles increase random impacts while preserving a wider free channel than stepped ramps. Alternating openings plus staggered fins reduce jams and keep die flow stable.

C — OVERALL ASSEMBLY ORDER

1) Print all sheets at 100% (no fit-to-page). 2) Score all fold lines before cutting. 3) Assemble body A + body B (Sheets 01-02) and keep seam open for insert steps. 4) Assemble base tray (Sheet 05): F1-F4 valley, F5 mountain, glue corners. 5) Install B1 in upper zone and B2 below it with 25-30 mm gap; tabs glue to opposite walls. 6) Install D1-D6 fins on left/right walls, staggered, fold angle 30-45° toward center. 7) Close body seam, attach base tray, verify center channel ≥ 30 mm, run d6 drop test.

D — TEST CRITERIA

• Target pass: d6 $\geq 95\%$ exit, d20 $\geq 90\%$ exit, no persistent jam points. • If jams occur, reduce fin angle or widen center lane before re-test. • Keep glue beads thin and avoid spill in window/opening zones. • Recommended cardstock: 200-250 gsm.

LEGEND

CUT

VALLEY FOLD

MOUNTAIN FOLD

GLUE TAB

NOTCH – CUT & REMOVE

