RTL Viewer - //vmware-host/Shared Folders/Documents/DEV/plasmax/proj/quartus/PLASMA_DE1_SOC - PLASMA_DE1_SOC

File Edit View Tools Window Help

Search altera.com

Page: 1 of 1

Netlist Navigator

PLASMA_DE1_SOC

Instances

plasma_de1_soc:plasma_de1_s

Instances

altera_reset_controller:rs

altera_reset_controller:rs

plasma_de1_soc_hps_0

plasma_de1_soc_mm_i

plasma_soc_top:plasma

Instances

plasma_soc:u_s

Instances

arbiter:arb

avalon_sl

master_c

Instar

m

Primi

Ports

shared_b

slave_co

slave_co

slave_co

slave_co

slave_ext

slave_gpi

slave_gpi

slave_gpi

slave_gpi

slave_irc

slave_me

Instar

ra

Primi

Ports

slave_spi

slave_tim

slave_tim

slave_tim

slave_tim

slave_uar

Primitives

Ports

Primitives

Ports

Ports

Ports

PLASMA_DE1_SOC:1

reg_bankcu4_reg_bank

clk

pause

rd_index[5..0]

rt_index[5..0]

reset_in

rs_index[5..0]

reg_dest_new[31..0]

Equal0

A[5..0]

6'h2e B[5..0]

OUT

Equal1

A[5..0]

6'h2c B[5..0]

OUT

Equal3

A[1..0]

2'h0 B[1..0]

OUT

intr_enable_reg~1

0

1'h0 1

intr_enable_reg~0

0

1

intr_enable_reg

D

CLK

Q

1'h0

SCLR

CLRN

Mux0

SEL[1..0]

DATA[3..0]

OUT

32'h0

intr_enable

reg_target_out[31..0]

reg_source_out[31..0]

reg_source_out[4]34641

100%

00:00:30