

Lab 2 — Create a Terrain and Building Pad

Autodesk Revit Architecture Masterclass (C508) · Topic 01: Design Modeling in Revit · Tertiary
Infotech Academy Pte Ltd

Goal

Add a toposurface to the building site by placing points at different elevations, then cut a building pad into the terrain based on the footprint of the foundation walls.

You'll build

A landscaped site with a graded toposurface, a grass material and a building pad ready for the model.

Tools: Revit · Toposurface · Building Pad · Section Box

Files in this lab

- LittleHouse.rvt (open in Autodesk Revit)

Step-by-step

1. Open the site plan view of the project.

Project Browser ► Floor Plans ► Site

2. Start the Toposurface tool and place boundary points at elevation 0.

Massing & Site ► Model Site ► Toposurface ► Place Point ► Elevation 0

3. Raise the far points: change the elevation on the Options Bar as you place them.

Options Bar ► Elevation 900 ► click to place the back points

4. Assign a grass material to the surface, then finish it.

Properties ► Material ► Grass ► Finish Surface

5. Sketch a building pad over the foundation footprint on the lower level.

Massing & Site ► Model Site ► Building Pad ► Pick Walls ► Finish

6. Frame the result in 3D with a section box to see the pad cutting the terrain.

3D view ► Properties ► Section Box ✓ ► drag the handles

Test it

The 3D view shows the terrain with a grass material, and the building pad cuts a level recess into the toposurface at the foundation walls.

